

# DIGITAL PANEL METERS

programmable  $\pm 10\,000$  points

## DGN 10



### ***User handbook***

*Valid for instruments with version 01.XX*

**KLAY-INSTRUMENTS B.V.**

Nijverheidsweg 5  
Postbus 13  
Tel. 0521-591550  
Fax 0521-592046

7991 CZ DWINGELOO  
7990 AA DWINGELOO  
Nederland  
E-mail: info@klay.nl

<b>1 . INTRODUCTION</b>	p2		
<b>2 . SPACE REQUIREMENTS</b>	p3		
<b>3 . CONNECTINGS</b>	p4		
<b>4 . PROGRAMMING</b>	p5		
4.1 Communication with the instrument	p5		
4.2 Orientation through the programming	p5		
4.3 Main menu	p5		
4.4 Programming menu	p6		
4.4.1 - Programming of the input	p6		
<i>a / Process signals</i>	p6		
<i>b / Temperature signals</i>	p7		
<i>c / Resistive sensors</i>	p7		
4.4.2 - Programming of the display factor	p8		
4.4.3 - Programming of the analog output	p8		
4.4.4 - Programming of the relay outputs	p9		
4.4.5 - Programming of the safeties	p9		
4.4.6 - Programming of the display	p10		
4.5 Features of the inputs and programming limits	p10		
4.5.1 - Current and voltage input	p10		
4.6 Features of the outputs and programming limits	p11		
4.6.1 - Analog output	p11		
4.6.2 - Relay outputs	p12		
4.6.3 - Safeties	p13		
4.6.4 - Display features	p14		
4.7 Reading of the configuration	p14		
4.8 Access code	p15		
		4.9 Programming of a new access code	p15
		4.10 - Functions which can be accessed in the main menu	p15
		4.10.1 - Display simulation	p15
		4.10.2 - Simulation of the analog output	p16
		4.10.3 - Menu CLEAR :	
		Deleting of the recorded alarms	p16
		4.10.4 - Menu CLr.tA:	
		Suppressing of the programmed tare	p16
		<b>5 . FUNCTIONS WHICH CAN BE REACHED FROM THE FRONT FACE</b>	p17
		5.1 Functions which require pressing only 1 key	p17
		<i>a / Display of the min. value</i>	p17
		<i>b / Display of the max. value</i>	p17
		<i>c / Deleting of the min. and max. values</i>	p17
		5.2 Functions which require pressing several keys	p17
		5.2.1 - Display shifting	p17
		5.2.2 - Visualisation of the direct measure	p18
		5.2.3 - Visualisation and setting of the alarm setpoints	p18
		5.2.4 - Setting of the tare (processs input only)	p18
		<b>6 . ERROR MESSAGES</b>	p19
		<b>7 . GENERAL WARRANTY TERMS</b>	p19
		<b>8 . LEXIQUE</b>	p19

# 1. INTRODUCTION

The **DGN 10** is a high accuracy digital panel meter. It is equipped on front face with a four 14 mm high red digits display, whose brightness suits applications in industrial control rooms perfectly. It allows the display, the control and the transmission of data from any measurable magnitudes.

## AVAILABLE OPTIONS: (specify on order)

### Insulated analog output: A

Active current output, or voltage.  
Programmable scale ratio with enlarging effect.

### Relay output: R

2 relays: mode setpoint or window.  
Recording of the alarms.  
Time delay and hysteresis adjustable on each setpoint.  
Alarm messages.

### CODING:

- Type: DGN 10
- Output options:  
A : Analog (A1 or A3: specify)  
R : 2 relays  
These options can be combined simultaneously.

### Order example:

For a digital panel meter with 1 active current analog output and 2 relays, request reference DGN 10 A1R.

## Features of the inputs

Types of INPUTS	Measure range adjustable from:		Permanent overload	Intrinsic error	Input impedance
mA ♣	-2 to +22mA		±100mA	< ±0.1% of the MR	Max. drop 0.9V
mV ♣♣	-10 to +110mV		±1V		≥ 1 MΩ
V ♣	-0.1 to +1.1 V		±50V		
	-1 to +11V		±600V		
	-30 to +330V				
Thermocouples ♣ Standard IEC 581	°C	°F	-	< ±0.1% <sup>♦(2)</sup> of the MR	≥ 1 MΩ
J	-160/1200	-256/2192			
K	-270/1370	-454/2498			
B	200/1820	392/3308			
R	-50/1770	-58/3218			
S	-50/1770	-58/3218			
T	-270/410	-454/770			
E	-120/1000	-184/1832			
N	0/1300	-32/2372			
L	-150/910	-238/1670			
W	1000/2300	1832/4172	-	< ±0.1% of the MR	Current 250μA
W3	0/2480	32/4496			
WRE5	0/2300	32/4172			
Sensor Pt100Ω <sup>(1)</sup> ♣ 3 wire, Standard IEC 751 (DIN 43760)	°C	°F	-	< ±0.1% of the MR	Current 250μA
Sensor Ni 100 3 wire <sup>(1)</sup> ♣	-60/260	-76/500	-	< ±0.1% of the MR (0.5% for 0-2KΩ)	-
Resistive sensors	Calibers 0-440 Ω and 0-2.2 kΩ ♣ (0-8.8 kΩ optional)			< ±0.1% of the MR (0.5% for 0-2KΩ)	-
Potentiometer	from 100Ω to 10 kΩ ♣				
Supply for 2 or 3-wire sensor	24 Vdc ± 15% with protection from short-circuits. 25 mA max.				
Special linearisation programming up to 20 points	On input: mV, V, mA. Resistive sensors and potentiometer				

- (1) Line resistance <25Ω  
(2) Or 30 μV typical (60μV Max.)  
♦ CJC efficiency: ±0.03°C/°C  
±0.5°C  
from -5°C to +55°C  
MR Measure range

♣ Cut off : the display and the output remain at down scale for an input signal < value of the cut off, programmable from 0% to 100% of the input range.

♣ A 12 μA pulsed current allows the detection of line or sensor rupture  
Thermic drift <150ppm /°C

## Features of the outputs

Code	Types of OUTPUTS		Features
A1	1 insulated analog output	active current	Current: direct or reversed 0-20mA Load impedance $\leq$ Lr 600 $\Omega$
A3		or voltage	Voltage: direct or reversed 0-10V Load impedance $\geq$ Lr 500k $\Omega$
R	2 inverting relays		2 setpoints per relay configurable on the whole MR. Hysteresis programmable from 0 to 100%. Time delay programmable from 0 to 25 sec. (8A/250 VAC on resistive load)

## General features

### Galvanic partition:

2.5 kV eff. - 50 Hz - 1 min between supply, inputs, outputs

### Power supply:

Max. operating range	Power draw
20 to 270 V <sub>AC</sub> - 50/60/400 Hz and 20 to 300 V <sub>DC</sub>	3 W max. 5.5 VA max.


- Standard sampling time: 100 ms
- Common mode rejection rate: 130 dB  
Serial mode rejection rate: 40 dB 50/60 Hz
- Zero drift compensation and self-calibration
- **Conform** with standards IEC 61000-6-4 on rejections and IEC 61000-6-2 immunity (in industrial environment) IEC 61000-4-2 level 3, IEC 61000-4-3 level 3, IEC 61000-4-4 level 4, IEC 61000-4-6 level 3.  
CE marking according to the directive EMC 89-336.

## 2. SPACE REQUIREMENTS

### Case dimensions: (with terminals)


96 x 48 x 124 mm

Mounting panel  
max. thickness: 30



### Panel mounting

cut out 44 x 91 mm



### Protection :

Front face: IP 65  
Housing: IP20  
Terminals: IP 20


### Housing:

Self-extinguishing case of black UL 94 V0 ABS.

**Plug off connectors** on rear face for screwed connectings (2.5mm<sup>2</sup>, flexible or rigid)





**Display:** ±10 000 points (14 mm)  
Electroluminescent red (green optional)  
2 alarm leds

# 3. CONNECTINGS



**Location of the terminals**  
(view of case rear side)


## INPUTS



# 4. PROGRAMMING

## 4.1 Communication with the instrument

Several functions can be accessed directly on front face:



Further functions can be accessed by pressing several keys simultaneously:

- + Setting of the display down scale; (see p17)
- + Setting of the display full scale; (see p17)
- + Visualisation of the direct measure (voir p18)
- + Visualisation and setting of the alarm setpoints; (see p18)

### Reading convention:


- Move through the main menu
- Revert to previous menu
- Blinking display: awaiting validation or setting
- Alternating information display

### Entering of a parameter:


- First start by increasing or decreasing the 1st digit and the sign: from -9 to +9. and
- 6888
- the 2nd from 0 to 9.
- 6588
- the 3rd from 0 to 9. Between each entering, validate the cipher with key
- 6528
- the 4th from 0 to 9.
- 6520

## 4.2 Orientation through the programming

The dialogue is ensured by 4 keys located on the front face.



**Note:** In mode programming, the instrument will automatically revert to the measure with the former configuration if no key is pressed during 1min.



#### 4.4 Programming menu *(according to options)*

▽	△	↻	InPut	Access to the programming of the input	p6
▽	△		diSPL.	Access to the programming of the display factor	p8
			AnA.	Access to the programming of the analog output <i>(option analog output)</i>	p8
			rELAY	Access to the programming of the relays <i>(option sortie relay output)</i>	p9
			SECU	Access to the programming of the outputs, the relays in case of error self-diagnosis and/or sensor rupture, and access to disconnecting the sensor rupture <i>(option analog or relay output)</i>	p9
			Pr.diS	Access to the programming of the display	p10
			SAvE	Access to the programming exit menu with or without saving of the configuration	p10

#### Note:

⇒ In mode programming, the instrument will automatically revert to measure with the former configuration if no key is pressed during 1min.

#### Note:


Press  to go on to next menu       Move through the menus / choice  


	Menu exit / access		Upwards move / increase
	Downwards move / decrease		Validation / vertical move

#### 4.4.1 Programming of the input

##### a. Process signals


InPut



**b. Temperature signals**

InPut

process signals



**Note:**  
Press to go to menu diSPL.


Move through the menus / choice

\* cold junction compensation, except thermocouple B which is only in CSF-E (external CJC)

**c. Resistive sensors**

InPut

temperature signals  
process signals



See also the features of the inputs **p10**

**Note:**

Press to go on to next menu



Move through the menus / choice



Menu exit / access



Upwards move / increase




Downwards move / decrease




Validation / vertical move

#### 4.4.2 Programming of the display factor



#### 4.4.3 Programming of the analog output (if option)



See also the features of the outputs p11

You can choose to assign the analog output to the input measure (PARA InPut) or to the displayed measure (PARA diSPL).

Eg.: with PARa diSPL

$$\boxed{d.out} = 4 \text{ mA} \quad \boxed{F.out} = 20.00 \text{ mA} \quad \boxed{dO.diS} = 20.0^\circ \quad \boxed{FO.diS} = 100.0^\circ$$


- When the transmitter indicates 20°C the value of the analog output will be 4 mA
  - When the transmitter indicates 100°C the value of the analog output will be 20 mA
- Eg.: with PARa InPut

$$\boxed{InPut} = 6 \text{ mA} \quad \boxed{d.out} = 4 \text{ mA} \quad \boxed{F.out} = 20 \text{ mA} \quad \boxed{dO.diS} = 6.0 \text{ mA} \quad \boxed{FO.diS} = 20.00 \text{ mA}$$

- When the value of the current measured on the input is 6.0 mA, the value of the analog output will be 4 mA
- When the value of the current measured on the input is 20.0 mA, the value of the analog output will be 20 mA


- Ⓜ Menu exit / access
- ⬆ Downwards move / decrease
- ⬆ Upwards move / increase
- ⏪ Validation / vertical move

#### 4.4.4 Programming of the relay outputs (if option)




See also the features of the relay outputs p12

#### 4.4.5 Programming of the safeties




#### 4.4.6 Programming of the brightness, of the display

Pr.diS



#### Exit from the programming with or without saving



SAVE

**Note:** An exit from mode programming with saving of the configuration (SAVE, YES) will automatically reset to zero the tare, the min. and the max. as well as the alarm recordings.

#### 4.5 Features of the inputs and programming limits

##### 4.5.1 Current input [MA] and voltage [U]

Special linearisation: [Li.SPE]

For specific applications such as the measurement of volume, the meter can memorise an unlinear curve, programmable in X and in Y.


The curve resulting from your equation can be replaced by a series of linear segments, with a maximum of 20 points (19 segments).

**Note:** The values of the abscisses (x) must go increasing d.in < value of A01 < value of A02... < F.in.

**Example :**

For a layed cylindric tank, 1 meter high (h) and 1 meter long (l); a 0-20 mA linear sensor measures the height of the liquid surface line:

**Input of the meter:** height h  
 0 meter -> 0 mA (empty tank)  
 1 meter -> 20 mA (full tank)  
 with  $\cos \beta/2 = (R-h)/R$   
 $\sin \beta/2 = C/2R$



Display of the meter:

Empty tank volume d.diSP = 0.000

Full tank volume F.diSP = 0.785

$$\text{Volume} = L [\pi R^2 \beta / 360 - C(R-h)/2]$$

Say a curve of 10 equally long segments:

Measure range / number of segments = 20mA/10 = 2mA length of the segment. For 10 segments nb = 9 (11 points to be programmed, including d.in and F.in).

Input mA	Height m	Degree	Chord m	Volume m <sup>3</sup>	Outputs in mA
d.in 0	0.0	0.00	0.00	d.diSP 0.000	00.00
A01 2	0.1	73.74	0.60	B01 0.041	01.04
A02 4	0.2	106.26	0.80	B02 0.112	02.85
A03 6	0.3	132.84	0.92	B03 0.198	05.04
A04 8	0.4	156.93	0.98	B04 0.293	07.47
A05 10	0.5	180.00	1.00	B05 0.393	10.00
A06 12	0.6	203.07	0.98	B06 0.492	12.54
A07 14	0.7	227.16	0.92	B07 0.587	14.96
A08 16	0.8	253.74	0.70	B08 0.674	17.17
A09 18	0.9	286.76	0.60	B09 0.745	18.98
F.in 20	1.0	360.00	0.00	F.diSP 0.785	20.00


**Programming:**

d.in = 0 mA      F.in = 20 mA

nb = 9

d.disp = 0,000 m<sup>3</sup>    F.disp = 0,785 m<sup>3</sup>

Programming from A01 to A09 and from B01 to B09 according to the table.



**4.6 Features of the outputs and programming limits**

**4.6.1 Analog output**

Out.i or Out.U

**0/4-20mA active current output, or 0-10V voltage output**

- Accuracy: 0.1 % in relation to the display (at +25°C)
- Residual ripple ≤ 0,2%
- Admissible load  $0\Omega \leq Lr \leq 600\Omega$  (current)  
 $Lr \geq 500\text{ k}\Omega$  (voltage)
- Scale ratio programmable with enlarging effect
- Response time: 40 ms in relation to the display

d.out Down scale of the analog output (eg. 04.00 (4mA))

F.out Full scale of the analog output (eg. 20.00 (20mA))

d0.diS Display value corresponding to the output down scale

F0.diS Display value corresponding to the output full scale

In mode measurement, the analog output can not overstepp 10% of the greatest of the 2 values : d.out and F.out

### 4.6.2 Relay outputs :

2 relay outputs

- Hysteresis independently programmable in the display unit.
- Time delay independently programmable from 0 to 25 s, in 0.1s increments.
- NO-NC contact 8 A - 250 V on resistive load


Activation or de-activation of alarm x

The status of relay x depends on the performed programming

The relay X remains still

Choice of the operating mode:

#### • Mode setpoint



**Legend:**


ON coil supplied  
OFF coil not supplied

Choice of the setting unit of the setpoints and hysteresis

setpoints and hysteresis in input scale points

setpoints and hysteresis in display points

#### • Mode window



Choice of the status of the relay associated led


The led indicates the alarm status.

Led lit when relay active (coil supplied)


Led still when relay active (coil supplied)

Setting of the hysteresis in display points  
The hysteresis is active on switching from lit led to still led; that is to say on switching out of alarm, as the led represents the alarm status.

#### • Mode setpoint



#### • Mode window



#### • Time delay on the alarm

The relay time delay can be adjusted from 000.0 to 025.0s, in 0.1s increments. It is active both on switching and switching back.

#### • Recording of the alarms

Allows recording the alarm after a setpoint has been passed. When the measure reverts below the alarm setpoint, the relay remains on and the led blinks to warn the user that a setpoint has been passed (to reset the alarm recordings to 0 see menu ).

**Note:** An exit from mode programming with saving of the configuration will reset the alarm recordings to zero.

#### • Display of the alarm messages

A programmed alarm message can be made to appear alternating with the measure. The message will appear only during the alarm, while the associated led is lit.

#### • Setting of the setpoints: there are 2 ways to adjust setpoints:

- either in mode programming entering the correct access code,
- or by pressing simultaneously on  and  if the access to a quick entering has been authorized on the programming of the code (see p18).

### 4.6.3 Safeties:

#### • Self-diagnosis:

The meter permanently watches any drifts which may occur on its components. The self-diagnosis serves to warn the user in case of abnormal increase of these drifts before they may provoke false measures.

#### The information of self-diagnosis error can be reported:

· On the display: An error message appears alternating with the measure; an error code is registered and can be read in the menu About

#### Coding:

- 1 : Programming error
- 2 : Offset error
- 4 : Input calibration error
- 8 : Output calibration error
- 64: Upper or lower electrical overstepping of the input

If the instrument detects for instance an offset error (2) and a programming error (1) **the value of the error code will be 3** (2+1).

#### · On the relays:

- No influence on the relay in case of self-diagnosis error
- Relay de-activated (coil not supplied) in case of self-diagnosis error
- Relay active (coil supplied) in case of self-diagnosis error

*Note : The led is either still or lit according to its programming in the menu rELAY.*

#### · On the analog output

If a return value has been entered  
Value between: 0 and 22 mA (current output)  
or 0 and 11 V (voltage output)

· On the converter: the led ON blinks fast

#### • Sensor rupture

The sensor rupture can be detected on inputs mV, Tc, Pt100, Ni100, resistance, and current if the down and full scale > 3.5 mA.

#### The information of sensor rupture can be reported:

##### · On the relays

- No influence on the relay in case of sensor rupture
- Relay de-activated (coil not supplied) in case of sensor rupture
- Relay active (coil supplied) in case of sensor rupture

Note: the led is either still or lit according to its programming in the menu rELAY.

##### · On the analog output

If a return value has been entered  
Value between: 0 and 22 mA (current output)  
or 0 and 11 V (voltage output)

· On the display: Message

Note: The sensor rupture detection has a priority over the self-diagnosis.

· On the converter: the led ON blinks slowly

#### • Disconnection of the sensor rupture (If input mV or temperature)

The sensor rupture detection can be disconnected in order not to disturb some calibrators which may be sensitive to the detection current.

#### In the menu

- Validation (or not) of the sensor rupture detection
- Detection active
- Detection inactive

#### 4.6.4 Display features:

Place of the decimal point for the inputs other than temperature inputs

Display resolution for the temperature inputs: **0.1°** or **1°**

Display corresponding to the input down scale (except the temperature input)

Display corresponding to the input down scale (except for the temperature input)

Only for the inputs process, resistance, potentiometer, expressed in display points.

– If the display full scale > display down scale and if the display is ≤ to the cut off value, then it will be held at down scale.

– If the display full scale < display down scale and if the display is ≥ to the cut off value, then it will be held at down scale.

#### • Response time:

Integration indice of the digital filtering:  
Programmable from 0 to 10; for use in case of unsteady input signal.

intEG	0	1	2	3	4	5
Typical response time at 90%	120 ms	400 ms	600 ms	1 s	1.4 s	2 s
		6	7	8	9	10
		3 s	5 s	7.5 s	10 s	15 s

To obtain the maximum response time, add 240 ms.

**Note:** For the response time of the analog output, add 40ms to the values shown in the table.

For the relays : add the time delay programmed on the alarms.

#### • Setting of the digits brightness

Lowest brightness

Strongest brightness

#### • Inhibition of the last digit (bottom weight)

In the mode programming, the menu L.dIG allows suppressing the display of the last digit, the latter being enforced to 0 if OFF is validated.

#### • Deleting of the insignificant zeros

=  Suppresses the display of the insignificant zeros on the left hand side.

**Eg.:** Display value 0015

=  Display = 0015


=  Display = 15

**Eg.:** Display value 00.15

=  Display = 00.15

=  Display = 0.15

#### 4.7 Reading of the configuration



In each reading submenu, use keys  and  to move, and key  to visualise the parameters.


If no key is pressed during 20 s., the instrument will revert to the measure display.

## Submenu

XXXXX  
1 2 3 4 5.

X1 : - : No analog output  
A : Analog output

X2 X3 : - - : No relay output  
r - : Output 2 relays




## 4.8 Access code

An access code adjustable from 0000 to 9999 serves to protect the meter and its setpoints from unauthorized programming, and to lock the access to some functions.

0 0 0 0	Factory code
x x x x	
0 to 5	Access to the display shifting
6 to 9	No access
0 to 5	Access to the display and output simulations
6 to 9	No access
0 to 5	Access to the function "tare" (except temperature inputs)
6 to 9	No access
0 to 5	Access to the quick entering of alarm setpoints
6 to 9	No access

## 4.9 Programming of a new access code




**Reminder:** If no key is pressed during 1 min, the instrument will revert to the measure display. On factory exit, the access code is 0000.

## 4.10 Functions which can be reached from the main menu

### 4.10.1 Simulation of the display

(accessible according to the programmed access code and if option relay outputs or analog output)


The display can be simulated with the meter in order to validate the configuration of the analog output and the relays in the installation.



**Note:** The instrument will no longer measure during the simulation. The analog output and the relay outputs will react according to the entered display. If alarm messages have been programmed, they may appear during the simulation.

#### 4.10.2 Simulation of the analog output (mode generator)

(accessible according to the programmed access code and if option analog output)




**Note:** The instrument will carry on measuring during the simulation. Only the analog output will no longer react to the measure.

#### 4.10.3 Menu `CLEAr` : Deleting of the recorded alarms

If the function recording of alarms has been programmed: the status of the relay will be recorded after the setpoint has been passed.

If the setpoint is passed back the other way, the status of the relay does not change and the corresponding led starts to blink.


To revert to the normal status (led not blinking and relay in the correct state) use menu `CLEAr`.



**Reminder:** If no key is pressed during 20 s., the instrument will revert to the measure display.

**Note:** An exit from mode programming with saving of the configuration will reset the alarm recordings to zero.

#### 4.10.4 Menu `CLr_tA` : Suppressing of the programmed tare (accessible according to the programmed access code)




**Reminder:** If no key is pressed during 20 s., the instrument will revert to the measure display.


## 5. FUNCTIONS WHICH CAN BE REACHED ON THE FRONT PANEL

### 5.1 Functions which require pressing only 1 key:


#### a / Display of the min. value



#### b/ Display of the max. value



#### c / Deleting of the min. and max. values



 The instrument will revert to the measure display.

**Reminder:** If no key is pressed during 20 s., the instrument will revert to the measure display.

**Note:** An exit from mode programming with saving of the configuration will reset the min. and max. values to zero.

## 5.2 Functions which require pressing several keys:

### 5.2.1 Shifting of the display

(accessible according to the programmed access code)

-   Shifting of the display down scale (Adj.Lo)
-   Shifting of the display full scale (Adj.Hi)

After injecting an input signal corresponding to the down (or full) display scale, press the keys  and  (or  and ) simultaneously. The message Adj.Lo (Adj.Hi) will appear alternating with the value, to indicate that you are in the menu adjustment.

By pressing  and  you can increase or decrease the down (or full) display scale.

If you keep pressing during 3s. on key  or  you can access a quick increasing or decreasing of the display value.

Press  to validate the shifting. The message OK will appear during the acknowledgement of the shifting (1s.), and the instrument will revert to mode measure. Once all the shifting are validated, the input thus shifted will keep this shifting even after a setting off tension.

Press  (or do not press any key during 20 s) to revert to the measure display without modifications.

#### • Case of a process, resistance or potentiometer input

The instrument will then re-adjust its scale factor and its display factor in order to obtain the required result on the display.

#### • Case of a temperature input

On a temperature input; if 1 of the 2 settings is performed: this will correspond to an offset, which means that all the points will be shifted by the same quantity.

On the contrary, if the 2 settings are performed, the slope and the offset will be corrected in order to obtain the required result.


#### example :

On a Pt100 input for 0°C, the obtained display is -000.3

For 500°C the obtained display is 0500.2. To correct this display, shift the display down scale by 3 points to obtain 000.0, and the display full scale by -2 points to obtain 0500.0.

note: only for **temperature inputs**:

From the menu rEAd, the performed scale shiftings can be visualised in the submenu InPut :



Suppressing of the input shifting:

(Case of a temperature input only)

The menu AdJuS. in the mode programming of a temperature input allows suppressing the entered shifting, or not.

**no** : the instrument will revert to the factory settings

**Yes**: the instrument will take the programmed (offset and/or slope) adjustments into account.

### 5.2.2 Visualisation of the direct measure

Press and to visualise the signal directly without processing: scale factor, square root, linearisation

- in mV, V or mA for process inputs,
- in mV for thermocouple inputs,
- in  $\Omega$  for Pt100, Ni100 inputs,
- in  $\Omega$  for resistance inputs,
- in percents for potentiometer inputs.

### 5.2.3 Visualisation and setting of the alarm setpoints

**Option 2 or 4 relays**

**Setting of the setpoints:** There are 2 ways to adjust setpoints :

- either in mode programming entering the correct safety access code (see p15)

- or by pressing simultaneously on and

The meter will then show the message SP.x or SPx.x alternating with the value of the corresponding setpoint.

The values of the various setpoints can be accessed with and .

These setpoints can then be modified (if access code < 6000 (see p15)) by pressing

When the setpoint is adjusted press to revert to the setpoints reading menu.

Once all the setpoints are adjusted, simply press and the meter will revert to mode measure, taking the new values into account.

If no key is pressed during 60 s. the meter will revert to the measure display without modification of the value of the setpoints.

### 5.2.4 Setting of the tare (except temperature inputs)

(accessible according to the programmed access code)

Press and to enforce the display for the signal currently present on the input as the display down scale d.diSP

Note : The tare will not be memorised in case of power supply cut.

To suppress the tare, validate the menu CLr.tA in the main menu p16.

An exit from mode programming with saving of the configuration will reset the tare to zero.

## 6. ERROR MESSAGES

2000	Measure in overrange	----	Upper or lower electrical overstepping of the input
OPEn	Sensor rupture	O.L	Displayable value overload.
Err.1	Value set out of range To enter the value again, press 	Er.xxx	Self-diagnosis error (see page 13)

## 7. GENERAL WARRANTY TERMS

### WARRANTY applying and duration

This appliance is guaranteed for a duration of 1 year against any design or manufacturing defects, under normal operating conditions.

**Processing conditions \*** : Processing not under warranty will be submitted to the acceptance of a repair estimate. The customer will return the products at his charge, and they will be restored to him after processing. Without a written agreement on the repair estimate within 30 days, products will not be held.

\* Complete warranty terms and details available on request.

## 8. LEXIQUE

Messages shown by the meter in mode programming and/or in mode reading

### General access

rEAd	Access to the reading of the parameters
ProG	Access to the programming of the input and output parameters
CodE	Code for access to the programming of the input and output parameters
PCodE	Programming of a new access code
SiMUL	Access to the display simulation
GEnE.	Access to the simulation of the analog output
CLEAr	Deleting of the recorded alarms

## Inputs

InPut	Access to the input programming submenu	
TYPE	Input type	
U	Voltage input	
MA	Current input	
tEMP	Temperature input	
Pot	Potentiometer input	
rES	Resistance input	
Potentiometer and resistance input	Pot	rES
CALib	Choice of the resistance caliber	
400		
2 000		
8000		
Voltage input and current input	U	MA
CAL	Choice of the voltage caliber	
10U	Input 0 to 10 V (or -10/10V)	
300U	Input 0 to 300 V (or -300/300V)	
100M	Input 0 to 100 mV (or -100/100mV)	
1U	Input 0 to 1 V (or -1/+1V)	
2.UirE	mA input with supply for 2-wire sensor	
Temperature input	tEMP	
CAPt.	Type of temperature sensor	
Pt100	Pt100 input	
tc	Thermocouple input	
tc--	Type of thermocouple	
tc.CA	Thermocouple K (see the table page 3)	
CJC	Type of cold junction compensation	
CJC-I	Internal CJC	
CJC-E	External CJC	

Value of the external CJC

Input NI100

Type of degree

Degree Celcius

Degree Fahrenheit

Shifting of the input

Offset shifting

Slope and offset shifting, display down scale

Adjusting of the display down scale

Slope and offset shifting, display full scale

Adjusting of the display full scale

### Display parameters

Submenu programming of the display features

Adjusting of the digits brightness (4 levels)

Lowest brightness       Strongest brightness

Last digit (bottom weight)

Last digit in service       Last digit enforced to 0

Deleting of the insignificant zeros

Yes       No

### Display

Access to the display programming submenu

Choice of the place of the decimal point in mode measure

Place of the decimal point

Choice of the processing function

Linear

Input down scale

Input full scale

Display down and full scale

Special linearisation

Number of linearisation points

Abscisse of a special linearisation point

Ordinate of a special linearisation point

Cut-off programmable or not

Display resolution for the temperature inputs

Resolution 1/10th of degree

Resolution 1 degree

Integration indice

### Analog output

Access to the voltage output programming submenu

Access to the current output programming submenu

Output range in input scale points

Output range in display points

Down scale of the analog output

Full scale of the analog output  
 Access to the display corresponding to the output down scale

Access to the display corresponding to the output full scale

## Relay outputs: x : 1 or 2

rELAY Access to the submenu programming of the relay outputs

rEL.x Access to the programming of the relay x

AL.x Activation of the relay output 1

ON Activation  OFF De-activation

PArA.

InPut Setpoint and hysteresis in input scale points

diSPL Setpoint and hysteresis in display points

ModE.x Operating mode of the relay x

\_ \_ | \_ \_  - | \_ \_ Mode setpoints

\_ | \_ | \_  | \_ \_ | \_ Mode window

SPx Value of the setpoint in mode setpoint

SP1.X Value of the 1st setpoint in mode window

SP2.X Value of the 2nd setpoint in mode window

HYS.t.x Value of the hysteresis in display points

tiME.x Time delay on relay X

LEdx Programming of the led associated with the relay

On Led lit when relay active (coil supplied)

OFF Led still when relay active (coil supplied)

MEM.x Recording of the alarm X

yES Recording  no No recording

MESSx Alarm message

yES Message  no No message

## Safeties

SECU Access to the submenu programming of the safeties

ruPt. Programming of the sensor rupture safety

CAPt. Validation (or not) of the sensor rupture

OFF Sensor rupt. inactive  On Sensor rupt. active

rEL.X Status of relay X in case of sensor rupture

OFF No sensor rupture associated with the relay

LO Relay de-activated in case of sensor rupture  
(coil not supplied)

HI Relay active in case of sensor rupture (coil supplied)

Out.U  Out.i Return value (or not) of the output  
in case of sensor rupture error

yES Return value required  no No return value

rEPLi Return value

dlAG. Programming of the self-diagnosis safety

rEL.X Status of relay X in case of self-diagnosis error

OFF No self-diagnosis associated with the relay

LO Relay de-activated in case of self-diagnosis error  
(coil not supplied)

HI Relay activated in case of self-diagnosis error  
(coil supplied)

Out.U  Out.i Return value (or not) of the output  
in case of self-diagnosis error

yES Return value required  no No return value

rEPLi Return value

### Saving of the configuration

SAVE	Saving of the configuration	
	YES	Saving
	NO	No saving
UAit	Awaiting transfer	

### Reading of the instrument internal features

About	Access to the submenu reading of the internal features	
DGN	Nam of the instrument	
dGNIO	Type of instrument	
Ar--	Options of the instrument (-:standard - A: analog output -R: relay output)	
n	xxxx	Identification number of the instrument
PROG	xxx	Programme version number
Err.	0002	Type of error
CH.SUM	65F2	Check sum of the programme

### Changing of the access code

P.CodE	Access to the submenu modification of the access code	
OLd	Enter the former access code	
NEU	Enter the new access code	
no	The entered code is not valid	

### Further functions

InF.	Display of the min. value
SuP.	Display of the max. value
CLr.M	Deleting of the min. and max.
CLEAR	Deleting of the recorded alarms

### Error messages

Err.1	Value set out of range
OPEn	Sensor rupture
2000	Blinking measure: measure in overrange
OL	Displayable value overload
----	Upper or lower electrical overstepping of the input
Erxx	Self-diagnosis error