

## PROGRAMMABLE CONVERTER

---

$\mu$ C 305  
 $\mu$ C 805 -  $\mu$ C 405



■ <b>Summary</b>	
<b>1 . EXTERNAL VIEW</b>	p2
<b>2 . SPACE REQUIREMENTS</b>	p4
<b>3 . WIRING</b>	p4
<b>4 . PROGRAMMING</b>	
4.1 Communication with the instrument	p5
4.2 Orientation through programming	p5
4.3 Main menu	p5
4.4 Programming menu	p6
4.4.1 - Input programming	p6
<i>a / Process signals</i>	p6
<i>b / Temperature signals</i>	p7
<i>c / Resistive sensors</i>	p7
4.4.2 - Display programming	p8
4.5 Measure display	p10
4.5.1 - Mode transmitter / indicator	p10
4.5.2 - Decimal point location / resolution	p10
4.6 Input features and programming limits	p11
4.6.1 - Current and voltage inputs	p11
4.7 Output features and programming limits	p12
4.7.1 - Analog output	p12
4.7.2 - Relay outputs	p13
4.7.3 - Safeties	p14
4.7.4 - Display features	p14
4.8 Configuration reading	p15
4.9 Access code	p16
4.10 Programming of a new access code	p16
4.11 Functions accessible in the main menu	p16
4.11.1 - Display simulation	p16

■ <b>Summary</b>	
4.11.2 - Analog output simulation	p17
4.11.3 - Erasing of recorded alarms	p17
4.11.4 - Teleloading of a programming file	p17
<b>5 . FUNCTIONS ACCESSIBLE DURING DISPLAY</b>	p18
5.1 Functions which require pressing only 1 key	p18
<i>a / min. value display</i>	p18
<i>b / Max. value display</i>	p18
<i>c / Erasing of min. and Max. values</i>	p18
5.2 Functions which require pressing several keys	p18
5.2.1 - Display shifting	p18
5.2.2 - Direct measure visualising	p19
5.2.3 - Visualising and setting alarm setpoints	p19
<b>6 . ERROR MESSAGES</b>	p19
6.1 Led ON flashing	
<b>7 . GENERAL WARRANTY TERMS</b>	p20
<b>8 . LEXIQUE</b>	p20

# 1. EXTERNAL VIEW

The series  $\mu\text{C}$  305 / 805 / 405, offers a broad range of fully programmable measurement interfaces.

## • Input features:

### **Direct voltage or current input**

Bidirectional  $\pm 100\text{mV}$ ,  $\pm 1\text{V}$ ,  $\pm 10\text{V}$ ,  $\pm 300\text{V}$ ,  $\pm 20\text{mA}$ .

- Accuracy: 0.05% of full scale at  $+25^\circ\text{C}$   
Thermic drift  $< 150 \text{ ppm}/^\circ\text{C}$
- Measurable scale overstepping from -5% to +5%
- Programmable scale factor
- Enlarging effect - Square root extraction
- Special linearisation in 20 points
- supply for 2 or 3-wire sensor  $26 \text{ V}_{\text{DC}}$  ( $\pm 15\%$ ) -25 mA protected from short-circuits

### **Thermocouple input:**

(J, K, N, S, B, W5, T, R, E, W, W3, L)

- Accuracy: 0.1% of full scale at  $+25^\circ\text{C}$ , or  $25\mu\text{V}$  typical ( $50\mu\text{V}$  max.)
- Thermic drift  $< 150\text{ppm}/^\circ\text{C}$   
C.J.C. efficiency:  $< 0.03^\circ\text{C}/^\circ\text{C} \pm 0.5^\circ\text{C}$  from  $-5^\circ\text{C}$  to  $+55^\circ\text{C}$

### **Sensor input: Pt 100 $\Omega$ , Ni 100 $\Omega$**

- Line resistance influence in 3-wire measurement included in the grade for  $0 < R_I < 25\Omega$
- Measurement of  $\Delta$  Pt100 2 wires from  $-200^\circ\text{C}$  to  $+270^\circ\text{C}$  ( $0 < R_I < 10\Omega$ ) (R max.  $400\Omega$ )
- Max. measure current:  $250 \mu\text{A}$
- Accuracy: 0.1% of full scale at  $+25^\circ\text{C}$
- Thermic drift  $< 150\text{ppm}/^\circ\text{C}$ .

### **Resistive sensor:** calibers $0-400 \Omega$ and $0-2 \text{ k}\Omega$ ( $0-8 \text{ k}\Omega$ optional)

- Accuracy: 0.1% for calibers  $0-400 \Omega$  and  $0-8 \text{ k}\Omega$  and 0.5% for caliber  $0-2 \text{ k}\Omega$  (of full scale at  $+25^\circ\text{C}$ )
- Thermic drift  $< 150\text{ppm}/^\circ\text{C}$

### **Potentiometers:** from $100 \Omega$ to $10 \text{ k}\Omega$

- Accuracy: 0.1% of full scale at  $+25^\circ\text{C}$
- Thermic drift  $< 150\text{ppm}/^\circ\text{C}$

## • Output features:

### $\mu\text{C}$ 305, $\mu\text{C}$ 805

#### **Insulated analog output:**

Programmable scale ratio with enlarging effect.

For a  $\mu\text{C}$  305, only 1 of the 2 analog outputs can be activated (outputs are not independent).

For a  $\mu\text{C}$  805, the analog output type (mA or V) must be specified on the order.

### $\mu\text{C}$ 805, $\mu\text{C}$ 405

#### **Relay output:**

4 relays: mode setpoint or window.  
Recording of alarms.  
Time delay and hysteresis adjustable on each setpoint.  
Alarm messages

Type	$\mu\text{C}$ 305	C - 2	
<b>Universal inputs</b>			
<b>Outputs:</b>			
$\mu\text{C}$ 305: 1 analog			
$\mu\text{C}$ 805: 1 analog, 4 relays			
$\mu\text{C}$ 405: 4 relays			
			<b>Power supply:</b>
			3 Low Voltage
			2 High Voltage
			<b>Version:</b>
			C case
			K rack (consult)

## Input features

Types of INPUTS	Measure range adjustable from:	Intrinsic error	Console resolution	Input impedance
mA	-22 to +22mA with $\sqrt{\clubsuit}$	< $\pm 0.05\%$ of MR	10 $\mu$ A	5 $\Omega$
mV $\spadesuit$	-110 to +110mV with $\sqrt{\clubsuit}$		10 $\mu$ V	
V	-11 to +11V with $\sqrt{\clubsuit}$		Input resolution: 14 bits	
	-330 to +330V with $\sqrt{\clubsuit}$	10mV		$\geq 1\text{M}\Omega$
Thermocouples $\spadesuit$ Standard IEC 581	$^{\circ}\text{C}$ $^{\circ}\text{F}$	< $\pm 0.1\%$ $\spadesuit$ *** of MR	0.1 $^{\circ}\text{C}$ / 0.1 $^{\circ}\text{F}$	$\geq 1\text{M}\Omega$
J	-160/1200    -256/2192			
K	-270/1370    -454/2498			
B	200/1820    392/3308			
R	-50/1770    -58/3218			
S	-50/1770    -58/3218			
T	-270/410    -454/770			
E	-120/1000    -184/1832			
N	0/1300    -32/2372			
L	-150/910    -238/1670			
W $\spadesuit$	1000/2300    1832/4172			
W3	0/2480    32/4496			
WRE5	0/2300    32/4172			
Sensor Pt100 $\Omega$ $\spadesuit$ * 3 wire, Stand. IEC 751 (DIN 43760)	$^{\circ}\text{C}$ $^{\circ}\text{F}$ -200    -328 / 850    / 1562	< $\pm 0.1\%$ of MR	0.1 $^{\circ}\text{C}$ / 0.1 $^{\circ}\text{F}$	Current 250 $\mu$ A
Sensor Ni 100 3 wires $\spadesuit$	-60/260    -76/500			
Differential measurements from 2 sensors Pt100 $\Omega$ 2 wires Stand. IEC 751 $\spadesuit$ **	$^{\circ}\text{C}$ $^{\circ}\text{F}$ -200    -328 / 270    / 518			
Resistive sensor	Calibers 0-440 $\Omega$ and 0-2,2 k $\Omega$ $\clubsuit$ (0-8,8 k $\Omega$ optional)	< $\pm 0.1\%$ of MR (0.5% for 0-2K $\Omega$ )		-
Potentiometer	from 100 $\Omega$ to 10 k $\Omega$ $\clubsuit$			
2-wire sensor supply	26 V <sub>DC</sub> $\pm 10\%$ with protection from short-circuits.			
Special linearisation program. up to 20 points	On input: mV, V, mA. Resistive sensor and potentiometer			

\* Line resistance <25 $\Omega$

\*\* Line resistance <10 $\Omega$  and R. max. of 400 $\Omega$

\*\*\* or 25  $\mu$ V typical (50 $\mu$ V Max.)

$\spadesuit$  CJC efficiency:  $\pm 0.03^{\circ}\text{C}/^{\circ}\text{C} \pm 0.5^{\circ}\text{C}$  from -5 $^{\circ}\text{C}$  to +55 $^{\circ}\text{C}$

MR = Measure range

$\sqrt{\quad}$ : square root extraction

$\spadesuit$  A 12  $\mu$ A pulsed current allows line or sensor rupture detection

$\clubsuit$  Cut off: the console display and the  $\mu$ C output are held at down scale for an input signal < the cut-off value, programmable from 0% to 100% of the full input scale.

Thermic drift <150ppm / $^{\circ}\text{C}$

## Output features

$\mu$ C 305			$\mu$ C 805			$\mu$ C A05			Types of OUTPUTS	Features
$\bullet$	$\bullet$					Analog insulated	Current active / pass.	Voltage	Direct or inverted 0-20mA	
									Load impedance $\leq$ Lr 600 $\Omega$	
						4 relays with active contact (NO)			Direct or inverted 0-10V	
									Load impedance $\geq$ Lr 2000 $\Omega$	
									2 setpoints per relay configurable on the whole MR. Hysteresis programmable from 0 to 100%. Time delay programmable from 0 to 25 sec. (8A/250 VAC on resistive load)	



## General features

**Galvanic partition:** 2kV-50Hz-1min. between Supply, Input, Analog Output and Relay Outputs

	Type of SUPPLY	Max. operating range	Power draw	Dielectric withstanding
3	Low Voltage	20 to 40 V <sub>AC</sub> and 20 to 64 V <sub>DC</sub>	3 W max.	2KV-50Hz-1min.
2	High Voltage	90 to 270 V <sub>AC</sub> and 88 to 350 V <sub>DC</sub>	5 VA max.	

- Sampling time: 100 ms
- Common mode rejection rate: 130 dB  
Serial mode rejection rate: 70 dB 50/60 Hz
- Zero drift compensation and self-calibration
- **Complies** with standards EN 50081-2 on rejections and EN 50082-2 on immunity (in industrial environment)  
EN 61000-4-2 level 3, EN 61000-4-3 level 3,  
EN 61000-4-4 level 4, EN 61000-4-6 level 3.  
CE marking according to Directive EMC 89-336.

## 2. SPACE REQUIREMENTS



Mount the instruments vertically (on horizontal DIN rail) and provide a 3 mm spacing.

**Dimensions:** 26.5 x 80 x130 mm

**Case:** self-extinguishing In black UL 94VO ABS

Mounting in electrical switchbox: latching on symmetrical DIN rail

*Rack version: consult with us*

Plug-off connectors for screwed connections

(2.5mm<sup>2</sup>, flexible or rigid)

**Protection:** Case / terminals: IP 20


**Operating temperature:** -10 to 50°C

**Storage temperature:** -20 to 70°C


## 3. WIRING

Upper connector

Lower connectors



### OUTPUTS




## 4. PROGRAMMING

### 4.1 Communication with the instrument

Several functions can be accessed during measurement:

- Access to main menu p5
- Max. value display p18
- min. value display p18
- min. and Max. zero reset p18



Further functions can be accessed by pressing several keys simultaneously:

- + Adjusting of display down scale ; (see p18)
- + Adjusting of display full scale ; (see p18)
- + Direct measure visualisation; (see p19)
- + Visualisation and setting of alarm setpoints; (see p19)

### Reading convention:

- Move through main menu
- Return to previous menu
- Blinking display: awaiting validation or setting
- Alternate information display

### Entering of a parameter:

- First start by increasing or decreasing  
The 1st digit and the sign: from -9 to +9. and
  - The 2nd from 0 to 9. ....
  - The 3rd from 0 to 9. ....
  - The 4th from 0 to 9. ....
- Between each entering, validate the cipher by pressing


## 4.2 Orientation through programming

Dialogue is ensured by 4 keys located on the front face.

- Exit from a sub-menu to access next menu / access to the programming exit menu
- Move through menus : to the top, or increase the value shown
- Move through menus : to the bottom, or decrease the value shown
- Validation of the parameter shown, or access to a sub-menu

**Note:** In mode programming, the instrument will automatically resume measuring with the previous configuration if no key is pressed during 1min.

## 4.3 Main menu



## 4.4 Programming menu (according to options)

		<b>INP</b>	Access to input programming	p6
		<b>DISP</b>	Access to programming of the operating mode (mode indicator or mode transmitter)	p8
		<b>ANA</b>	Access to programming of the analog output <small>(option analog output)</small>	p8
		<b>REL</b>	Access to programming of the relays <small>(option relay outputs)</small>	p9
		<b>SECU</b>	Access to programming of the outputs, of the relays in case of self-diagnosis and/or sensor rupture, and access to disconnection of the sensor rupture <small>(option analog or relay output)</small>	p9
		<b>PrDI</b>	Access to display programming	p10
		<b>NAME</b>	Access to the $\mu$ C file name	p10
		<b>SAVE</b>	Access to the programming exit menu, with or without saving the configuration	p10

### Note:

⇒ In mode programming, the instrument will automatically resume measuring with the previous configuration if no key is pressed during 1min.

### Note:

Press to access next menu


Move through menus / choice

	Menu exit / access		Upwards move / increase
	Downwards move / decrease		Validation / Vertical move

## 4.4.1 Input programming

### a. Process signals

**INP**



### Note:


Press to access menu

**DISP**

**b. Temperature signals**

INP

process signals




\* cold junction compensation, except thermocouple B which is only in CJ-E

**c. Resistive sensors**

INP

temperature signals  
process signals



**Note:**

Press to access next menu



Move through menus / choice



Menu exit / access



Upwards move / increase




Downwards move / decrease




Validation / Vertical move



## 4.4.2 Display programming



## Option analog output



See also output features p12

**Example:** In mode indicator or for a temperature input:

$dOUT = 4 \text{ mA}$     $F.OUT = 20.00 \text{ mA}$     $dOdI = 10.0^\circ$     $F.OdI = 100.0^\circ$



the analog output value will then be 4 mA when the displayed measurement is 10.0°, and 20 mA for a displayed measurement of 100.0°.

**In mode transmitter.** Only d.OUT and F.OUT parameters are available


For a mA input with dINP = 0.00 and FINP = 20.00 mA if dOUT=4 mA and F.OUT = 20 mA. The analog current output value will be 4.00 mA for an input signal of 0.00 mA.

• valid if SCALE YES validated: mode indicator / temperature input

- Upwards move / Increase
- Downward move / decrease
- Menu exit / access
- Validation / Vertical move




PrDI



**Programming of the display brightness**

See also display features p16


NAME



**Note :** Press to access next menu Move through menus / Choice

	Menu exit / access		Upwards move / Increasing
	Downwards move / decreasing		Validation / Vertical move

**Programming exit with or without saving**



SAVE

**Note:** Exit from mode programming saving the configuration (SAVE, YES) will automatically reset the min. and max. as well as alarm recordings to zero. After SAVE, YES the µconsole shows WAIT during the converter re-initialisation phase.

**4.5 Measure display**

**4.5.1 Mode transmitter / indicator**

According to choice SCALE YES / NO, you will decide to have a physical scale for the converter, or not. SCALE YES lets parameters POIN (decimal point location) dDIS and FDIS (down and full display scale corresponding to the down and full input scale, selected in dINP and F.INP) and UNIT (unit of displayed physical magnitude) appear. With the configuration SCALE YES it may be considered that the converter operates as a meter which can display a measured physical magnitude locally.

**Example 1:** For a 4/20 mA signal coming from a level sensor on a tank, following programming is shown in menu INP: TYPE = mA, FUNC = LIN, dINP = 4.00, F.INP = 20.00, in menu DISP : SCALE YES, POIN =   .  , dDIS = 000.0, FDIS = 300.0, UNIT = LTS (liters) CUT = NO for:  
 4 mA from the sensor, display = 000.0  
 12 mA from the sensor, display = 150.0  
 20 mA from the sensor, display = 300.0

**In the case of MODE INDICATOR** (with a physical scale programmed by SCALE, YES), the parameters down and full display scale, set-points, hysteresis, dOdI and FIdI for the analog output, cut-off and ordinates (if input linearised in segments) are to be considered in the programmed physical scale magnitude.

For example 1, a setpoint on relay 1 (SP1.1) with a value of 30.0 corresponds to a setpoint of 30.0 I. If the display oversteps 30.0I (if the input oversteps 5.60 mA) the state of relay 1 will change.

**Note:** If you want to avoid overloading the programming with an unnecessary physical display, programme SCALE NO (mode transmitter). In this case, parameters POIN, DDIS, FDIS, UNIT, and dOdl and FOdl (if option analog output) do not need to be entered.

**In the case of MODE TRANSMITTER (SCALE NO)** the parameters setpoints, hysteresis, cut-off and ordinates (if input linearised by segments) are to be considered in the physical magnitude of the programmed input type (V, mA, Ω etc...).

In example 1, for the state of relay 1 to switch if the level oversteps 30.0I, you must enter a setpoint value of 1 SP1.1 = 5.60 for 5.60mA.

In mode transmitter, the resolution of parameters is commanded by the selected input type: 2 decimals for a mA input, 1 decimal for caliber 300V, etc... on the console display.

#### 4.5.2 Decimal point location / resolution

Parameter POIN is to be considered as a move of the decimal point, and not as a resolution. Parameter POIN is common to all parameters related to the display in the case of a programmed physical scale (down and full display scale, setpoints, hysteresis etc...).

In the case of a programming without a physical display scale, parameter POIN is not available and the decimal point location is set according to the chosen input type (see

To take up example 1, display = 300.0L for a 4-20mA input at 20mA, with a setpoint at 30.00L.

If you want measure to be displayed without decimals, i.e. for a 20mA input display = 300, change POIN from ---.- to ----. and divide by 10 all parameters related to the display.

In this example, after modifying parameter POIN from ---.- to ----. you must modify F.DIS from 3000. to 0300. and SP1.1 from 0300. to 0030. to obtain the required operating.

**Note:** For safety reasons, in case the user forgets after changing the decimal point location, (parameter POIN) or the operating mode (parameter SCALE) the transmitter will propose again after SAVE YES the list of parameters which have not been validated (see previous page).

For the temperature input, when the resolution is changed from RES=1°C to RES = 0,1°C or the contrary, the user will not need to modify again all the parameters related to the display.

Note following oddness on the µconsole, because it has only 4 digits :

If you are in RES = 1°C, with a setpoint SP1.1 = 1000 and if you modify RES = 0.1°C, the 0.1°C (which can not be shown on 4 digits) does not appear for this setpoint, which still appears as SP1.1 = 1000.

If you want to modify this setpoint to 900°C for instance, first enter 0900 and validate, and the converter will propose the value again with the possible resolution of 0.1°C programmed, i.e. 900.0.

## 4.6 Input features

### 4.6.1 Current input

mA

or voltage

V

### Square root extraction

ROOT

The function square root tends to amplify the input signal background noise as it gets near to zero.

To avoid the oscillations caused by this noise, simply programme a cut-off value (in display points).

If the display is below this value, it is maintained at down scale (if input full scale > input down scale) or at full scale (if input full scale < input down scale)

### Special linearisation:

SEGT

For specific applications such as volume measurement, the converter can memorise an unlinear curve, programmable in X and in Y.

The curve resulting from your equation can be replaced by a sequence of linear segments, with a maximum of 20 points (19 segments).

Note that X00 = dINP and for the last point abscisse XNB-1 = F.INP

**Note1:** The values of abscisses (x) have to go increasing. value of X00 < value of X01...


**Note2:** In special linearisation and in mode transmitter (SCALE NO), the displayed measure is the measure linearised by the programming of points. The undeformed input measure can always be accessed by function direct measure (see p20).

**Example:**

For a layed cylindric tank, 1 meter high (h) and 1 meter long (l); a linear sensor 0-20 mA measures the height of the liquid surface line:


0 meter -> 0 mA (empty tank) 1 meter -> 20 mA (full tank)  
 with  $\cos \beta/2 = (R-h)/R$  and  $\sin \beta/2 = C/2R$   
 Volume empty tank = 0.000  
 Volume full tank = 0.785

$$\text{Volume} = L [\pi R^2 \beta/360 - C(R-h)/2]$$



Say a curve of 10 equally long segments:  
 Measure range / Nr of segments = 20 mA/10 = 2 mA = segment length. For 10 segments Nr = 11 (number of linearisation points).

Input mA	Height m	Degree	Chord m	Volume m <sup>3</sup>	Outputs in mA
X00 0	0.0	0.00	0.00	Y00 0.000	00.00
X01 2	0.1	73.74	0.60	Y01 0.041	01.04
X02 4	0.2	106.26	0.80	Y02 0.112	02.85
X03 6	0.3	132.84	0.92	Y03 0.198	05.04
X04 8	0.4	156.93	0.98	Y04 0.293	07.47
X05 10	0.5	180.00	1.00	Y05 0.393	10.00
X06 12	0.6	203.07	0.98	Y06 0.492	12.54
X07 14	0.7	227.16	0.92	Y07 0.587	14.96
X08 16	0.8	253.74	0.70	Y08 0.674	17.17
X09 18	0.9	286.76	0.60	Y09 0.745	18.98
X10 20	1.0	360.00	0.00	Y10 0.785	20.00



**Programming:**  
 d.INP = 0 mA = X00  
 F.INP = 20 mA = X10  
 nb = 9  
 d.dis = 0.000 m<sup>3</sup> = Y00  
 F.dis = 0.785 m<sup>3</sup> = Y10

Programming from X00 to X10 and from Y00 to Y10 according to table.

**4.7 Output features and programming limits**

**4.7.1 Analog output** ANA

**Current output 0/4-20mA active or passive (Vmax.=30Vdc) or voltage output 0-10V (specify on order)**

- Accuracy 0.1 % in relation to display (at +25°C)
- Residual drift ≤ 0.2%
- Admissible load  $0\Omega \leq R_c \leq 500\Omega$  (current)  
 $R_c \geq 2\text{ k}\Omega$  (voltage)
- Programmable scale ratio with enlarging effect
- Response time: 40 ms in relation to display

- dOUT Analog output down scale (eg. 04.00 (4mA))
- F.OUT Analog output full scale (eg. 20.00 (20mA))
- dOdl Display value corresponding to output down scale
- FOdl Display value corresponding to output full scale

In mode measurement, the analog output can not exceed 10% of the greatest of the 2 values: dOUT and F.OUT

## 4.7.2 Relay outputs:

4 relay outputs

- Hysteresis programmable independently in the display unit
- Time delay programmable independently from 0 to 25 s in 0.1s increases
- NO-NC contact 8 A - 250 V on resistive load


Activation or de-activation of alarm x

The state of relay x depends on the performed programming

Relay x remains still.

Choice of the operating mode:


### • Mode setpoint



#### Legend:

ON coil supplied  
OFF coil not supplied

### • Mode window



If mode indicator (SCALE YES) is selected, the setting of setpoints is in display points.

If mode transmitter (SCALE NO) is selected, the setting of setpoints is in input scale points.

Choice of the relay associated Led


The Led indicates the alarm state.

Led lit when relay active (coil supplied)


Led still when relay active (coil supplied)

Hysteresis adjusting in display points if mode indicator (SCALE YES). The hysteresis is active on passing from Led lit to Led still ; i.e. on switching out of alarm, as the Led represents the alarm state.

### • Mode setpoint



### • Mode window



### • Alarm time delay

The relay switching time delay is adjustable form 000.0 to 025.0s. in 0,1s. increases. It is active both on switching and switching back

### • Alarm recording

Keeps a memory of alarms after a setpoint has been passed. As measure reverts below the alarm setpoint, the relay remains ON. The corresponding Led blinks to warn the user that a setpoint has been passed (to reset alarm recordings to zero see menu  p17)

Note: Exit from mode programming with configuration saving will automatically reset recorded alarms to zero.

### • Display of alarm messages

A programmed alarm message can be made to appear alternating with measure. The message will appear only during the alarm state, while the associated Led is lit.

### • Setting of setpoints:

- either in mode programming entering the correct access code
- or by simultaneous pressing on  +  if the access to quick entering has been authorized on programming of the code (see p16)

### 4.7.3 Safeties:

#### • **Self-diagnosis:**

DIAG

The converter permanently watches any drifts that may surge on its components. The self-diagnosis serves to warn the user in case of abnormal increase of these drifts, before they provoke false measures.

The self-diagnosis error information can be reported:

- On the display: An error message appears alternating with measure.

Coding:

- 1 : Programming error
- 2 : Gain error
- 4 : Offset error
- 8 : Input calibration error
- 16 : Output calibration error

64 : Input upper or lower electrical overstepping

If the instrument detects for instance an offset error (4) and a gain error (2) the **error code value will be 6** (4+2).

- On the relays:

OFF	No influence of a self-diagnosis error on the relay
LO	Relay de-activated (coil not supplied) in case of self-diagnosis error
HI	Relay activated (coil supplied) in case of self-diagnosis error

- On the analog output

If a return value has been programmed  
Value included between : 0 and 22 mA (current output)  
or 0 and 11 V (voltage output)

- On the converter: Led ON blinks fast

#### • **Sensor rupture**

RUPT

The sensor rupture can be detected on inputs mV, Cc, Pt100, Ni100, ΔPT100, resistance, and current if down and full scale > 3.5 mA.

The sensor rupture information can be reported:

- On the relay

OFF	No influence of sensor rupture on the relay
LO	Relay de-activated (coil not supplied) in case of sensor rupture
HI	Relay active (coil supplied) in case of sensor rupture

Note: the Led is either still or lit according to its programming in menu REL.

- On the analog output

If a return value has been programmed  
Value included between : 0 and 22 mA (current output)  
or 0 and 11 V (voltage output)

- On the display: Message OPEN

Note: The sensor rupture detection has priority over the self-diagnosis.

- On the converter: Led ON blinks slowly

#### • **Sensor rupture disconnection** (If input mV or temperature)

The sensor rupture can be disconnected to avoid disturbing some calibrators that may be sensitive to the rupture detection current.

In menu SECU :

CAPT	Validation (or not) of the sensor rupture
ON	Sensor rupture active
OFF	Sensor rupture inactive

### 4.7.4 Display features:

POIN	Decimal point location for inputs other than temperature inputs
RES	Display resolution for temperature inputs <b>0.1°</b> or <b>1°</b>
dDIS	Display corresponding to down input scale (except temperature input)
F.DIS	Display corresponding to full input scale (except temperature input)
CUT	Only for inputs process, resistance, potentiometer expressed in display points if mode indicator (SCALE YES).

– If display full scale > display down scale and if display ≤ cut off value, then it is maintained at down scale.

– If display full scale < display down scale and if display ≥ cut off value, then it is maintained at down scale.

• **Response time:**

Digital filtering integration indice:  
 Programmable from 0 to 10; for use in case of unsteady input signal.

FILT	0	1	2	3	4	5
Typical response time at 90%	120 ms	400 ms	600 ms	1 s	1.4 s	2 s
	6	7	8	9	10	
	3 s	5 s	7.5 s	10 s	15 s	

To obtain the maximum response time, add 240 ms.

**Note:** For the analog output response time, add 40ms to the values shown in the table  
 For the relays: add the time delay programmed on the alarms.

• **Adjusting of the digits brightness**

Lowest brightness       Strongest brightness

• **Last digit inhibition** (*low weight*)

In mode programming, menu LdIG enables display suppression of the last digit, the latter being enforced to 0 if OFF is validated.

• **Erasing of insignificant zeros**

=  Suppresses the display of insignificant zeros on the left hand side.

**Eg.:** Display value 0015

=  Display 0015  
 =  Display 15

**Eg.:** Display value 00.15

=  Display 00.15  
 =  Display 0.15

• **Display self-extinguishing**


Display permanently lit  
 After 10 min, display shows

In mode idle (display shows ), following messages can appear briefly every 5 seconds to indicate to the user that the transmitter is not in a standard measurement phase.

**Displayable messages:**

, , ,  or

**4.8 Configuration reading**




In each reading sub-menu, keys and are used to move, and key is used to visualise parameters.

If no key is pressed during 20 s., the instrument will automatically resume measure display.



## Sub-menu




## 4.9 Access code

An access code adjustable from 0000 to 9999 serves to protect the converter and its setpoints from unauthorized programming, and to lock access to some functions.

0 0 0 0	Factory code
x x x x	
⋮	0 to 5 Access to display shifting
⋮	6 to 9 No access
↓	
⋮	0 to 5 Access to display and output simulations
⋮	6 to 9 No access
↓	
⋮	0 to 5 Access to teleloading files
⋮	6 to 9 No access
↓	
⋮	0 to 5 Access to fast entering of alarm setpoints
⋮	6 to 9 No access

## 4.10 Programming of a new access code



**Reminder:** If no key is pressed during 1 min, the instrument will automatically resume measure display.


On factory exit, the access code is 0000.

## 4.11 Functions accessible in the main menu

### 4.11.1 Display simulation

(accessible according to the programmed access code and if option relays or analog output)


The display can be simulated with the converter in order to validate the analog output and relay outputs configuration in the installation.



**Note:** The instrument no longer measures during simulation. The analog output and the relay outputs react according to the entered display. If alarm messages have been programmed, they may appear during simulation.

#### 4.11.2 Analog output simulation (mode generator)

(accessible according to programmed access code and if option analog output)




**Note:** During simulation, the instrument keeps measuring, only the analog output no longer reacts to measure.

#### 4.11.3 Menu **CLrA** : Erasing of recorded alarms

If the function recording of alarms has been programmed:  
After the setpoint has been passed, the relay state is recorded.


If the setpoint is passed back, the relay state does not change and the corresponding Led starts to blink.  
To come back to the normal state (Led not blinking and relay in the correct state), use menu CLrA.



**Reminder:** If no key is pressed during 20 s., the instrument will automatically resume measure display.

**Note:** Exit from mode programming with configuration saving will automatically delete recorded alarms.

#### 4.11.4 Menu **LOAD** : Teleloading of a programming file



- save the μC programme in the μconsole memory.
- teleload the programming file from the μconsole to the μC.
- ERR** **PROG** Programming file not correct: belongs to another instrument type
- ERR** **OPT** File does not have the same options as the instrument currently in service

Eg. : a μC305 file can not be copied to a μC805. For the teleloading in the direction to be possible, the receiving converter must have the same input and output options as the converter from which the programming file has been copied.


The reading of the file stored in the μconsole is possible if you validate choice **READ** **CONS**. In this case the programming file reading organigramme is the same as for the instrument programming. (see p6)

**Reminder:** If no key is pressed during 20 s., or if you press the instrument will resume measure display.


## 5. FUNCTIONS ACCESSIBLE DURING DISPLAY

### 5.1 Functions that require pressing only 1 key:


#### a / min. value display.



#### b/ max. value display



#### c / Deleting of minimum and maximum values



(M) The instrument will resume measure display.

**Reminder:** If no key is pressed during 20 s., the instrument will automatically resume measure display.

**Note:** Exit from mode programming with configuration saving will automatically reset min. and max. values to zero.

### 5.2 Functions which require pressing several keys:

(accessible according to programmed access code)

#### 5.2.1 Display shifting

(A) (V) Display down scale shifting

(M) (A) Display full scale shifting

After injecting an input signal corresponding to the down (or full) display scale, press simultaneously on keys (A) and (V) (or (M) and (A)). The message ) will appear alternating with the value, to indicate you are in menu adjustment.

The down and full display scale can be increased or decreased by pressing (A) and (V). If you keep pressing (A) or (V) during 3 seconds you can access a fast increasing or decreasing of the value shown.

Press (M) to validate the shifting. Message appears during the shifting acknowledgement (1s.), and the instrument resumes measure. Once all shiftings are validated, the shifted input will keep this shifting even after setting OFF tension. Press (M) (or no pressing during 20 s.) to resume measure displays without modifications.

#### • Case of a process, resistance or potentiometer input

The instrument will then re-adjust its scale factor and display factor in order to obtain the required result on the display.

#### • Case of a temperature input

On a temperature input; if one of the 2 settings is performed, this will correspond to an offset, that is to say all points will be shifted by the same quantity.

On the contrary, if the 2 settings are performed, slope and offset will be corrected to obtain the required result.



#### example:

Say a PT100 input for 0°C. Display = -000.3

For 500°C you will obtain a display = 0500.2. To correct this display, shift the display down scale by 3 points to obtain 000.0, and the display full scale by -2 points to obtain 0500.0.

#### note: Only for temperature inputs:

From menu READ, performed scale shiftings can be seen in sub-menu INP:



Suppression of the input shifting:

(Case of a temperature input only)

Menu ADJ in the mode programming of a temperature input allows cancelling the entered shifting, or not.

**NO:** the instrument will revert to factory settings

**Yes:** the instrument will take the programmed adjustments into account (offset and / or slope)

**5.2.2 Direct measure visualising**

Press and to visualise the signal directly without processing: scale factor, square root, linearisation

- in mV, V or mA for process inputs
- in mV for the thermocouple input
- in Ω for the Pt100, Ni100 input
- in Ω for the resistance input
- in percents for the potentiometer input
- hot sensor temperature for the ΔPt100 input

**5.2.3 Visualisation and setting of alarm setpoints**

**Option 4 relays**

**Setting of setpoints:** There are 2 ways to adjust setpoints.

- either in mode programming entering the correct safety access code (see p16)

- or by simultaneous pressing on and

The converter will then show message SP.x or SPx.x alternating with the value of the corresponding setpoint.

The values of the various setpoints can be accessed with and

These setpoints can then be modified (if access code < 6000 (see p16)) pressing

Once the setpoint is adjusted press key to come back to the setpoints reading menu.

Once all setpoints are adjusted, just press, and the converter will revert to mode measurement, taking the new values into account. If no key is pressed during 60 s. the converter will automatically resume measure display without modification of the setpoint values.

**6. ERROR MESSAGES**

Measure in overstepping	Input upper or lower overstepping
Sensor rupture	Displayable value overstepping.
Value set out of range To enter the value again press key  (see p14)	Self-diagnosis error (see p14)

**6.1 Led ON blinking:**

**Fast blinking:** self-diagnosis active (display shows )

**Slow blinking:**

Sensor rupture detected (display shows )

Input upper or lower electrical overstepping (display shows )

The converter is blocked in mode or

## 7. GENERAL WARRANTY TERMS

### WARRANTY applying and duration

We guarantee this instrument, for a duration of 1 year from any design or manufacturing defects, under normal operating conditions.

**Intervening conditions \*** : Processing of goods not under warranty will be subject to the acceptance of a repair estimate. The customer will return the products at his expense, who will re-send the goods after processing. Without a written agreement on the repair estimate within 30 days, products will not be held.

\* Complete warranty details and terms available on request.

## 8. LEXIQUE

### Messages shown by the converter in mode programming and/or in mode reading

#### General access

LOAD	Access to teleloading of a programming file
READ	Access to reading of the parameters
PROG	Access to programming of the input and output parameters
CODE	Code for access to the programming of input and output parameters
PCOD	Programming of a new access code
SIMU	Access to display simulation
GENE	Access to the analog output simulation
CLrA	Deleting of recorded alarms

#### Inputs

INP	Access to the input programming sub-menu
TYPE	Type of input
V	Voltage input
mA	Current input
TEMP	Temperature input
POT	Potentiometer input
RES	Resistance input

Potentiometer input and resistance input

Input down scale

Input full scale

Choice of the processing function

Linear

Special linearisation

Number of linearisation points

Abscisse of a special linearisation point

Voltage and current input

Choice of the voltage caliber

Input 0 to 10 V (or -10/10V)

Input 0 to 300 V (or -300/300V)

Input 0 to 100 mV (or -100/100mV)

Input 0 to 1 V (or -1/+1V)

Down input scale

Full input scale

Choice of the processing function

Linear

Square root extraction

Special linearisation

Number of linearisation points

Abscisse of a special linearisation point

Temperature input

Type of temperature sensor

Pt100 input

Thermocouple input

Thermocouple type

Thermocouple K (see table page 3)

Type of cold junction compensation  
 Internal cold junction compensation  
 External cold junction compensation  
 Value of external cold junction compensation  
 Delta PT100 input  
 NI100 input  
 Type of degrees  
 Degree Celcius  
 Degree Fahrenheit

Input shifting  
 Offset shifting  
 Slope and offset shifting, display down scale  
 Display down scale adjusting  
 Slope and offset shifting, display full scale  
 Display full scale adjusting

### Display parameters

Display features programming sub-menu  
 Adjusting of digits brightness (4 levels)  
 Lowest brightness       Strongest brightness  
 Last digit (least significant)  
 Last digit in service       Last digit enforced to 0  
 Erasing of insignificant zeros  
 Yes       No

### Display

Choice to use either a display scale, or mode transmitter (display of measured magnitude)  
 Access to the display programming sub-menu  
 Choice of the decimal point location  
 Decimal point location

Display down scale  
 Display full scale  
 Ordinate of a special linearisation point

Cut-off programmable or not  
 Display resolution for temperature inputs  
 Resolution 1/10<sup>th</sup> of degree  
 Resolution 1 degree

Integration indice  
 Choice of 4 characters to define the display unit

### Analog output

Access to the voltage output programming sub-menu  
 Access to the voltage output programming sub-menu  
 Analog output down scale  
 Analog output full scale  
 Access to the display corresponding to the output down scale  
 Access to the display corresponding to the output full scale

### Relay outputs: x: 1 to 4

Access to the relay outputs programming sub-menu  
 Access to the programming of relay x  
 Activation of relay output 1  
 Activation       De-activation  
 Operating mode of relay x  
       Mode setpoint  
       Mode window  
 Value of setpoint in mode setpoint  
 Value of 1st setpoint in mode window  
 Value of 2nd setpoint in mode window  
 Hysteresis value, in display points  
 Time delay on relay X

LEDx Programming of the relay associated Led

ON Led lit when relay active (coil supplied)

OFF Led still when relay active (coil supplied)

MEM.x Recording of alarm X

YES Recording  NO No recording

MESx Alarm message

YES Message  NO No message

### Safeties

SECU Access to the safeties programming sub-menu

RUPT Programming of the sensor rupture safety

CAPT Validation (or not) of the sensor rupture

OFF Sensor rupt. inactive  ON Sensor rupt. active

REL.X State of relay X in case of sensor rupture

OFF No sensor rupture associated with the relay

LO Relay de-activated in case of sensor rupture (coil not supplied)

HI Relay active in case of sensor rupture (coil supplied)

OUT.U  OUT.I Return value (or not) on the output in case of sensor rupture

or

YES Return value requested  NO No return value

REPL Return value

DIAG. Programming of the self-diagnosis safety

REL.X State of relay X in case of self-diagnosis error

OFF No self-diagnosis associated with the relay

LO Relay de-activated in case of self-diagnosis error (coil not supplied)

HI Relay active in case of self-diagnosis error (coil supplied)

OUT.U  OUT.I Return value (or not) on the output in case of self-diagnosis error

or

YES Return value requested  NO No return value

REPL Return value

### Configuration saving

SAVE Configuration saving

YES Saving  NO No saving

WAIT Awaiting transfer

### Reading of the instrument internal features

INFO Access to the internal features reading sub-menu

$\mu$ C Instrument name

305 Instrument type:  $\mu$ C305,  $\mu$ C805,  $\mu$ C405

n<sup>0</sup>  xxxx Instrument identification number

PROG  xxx Instrument programme version number

ORIG  PC-X Instrument origin

CSUM  65F2 Programme check-sum

### Changing of the access code

PCOD Access to the access code modification sub-menu

OLD Enter former access code

NEW Enter new access code

NO Entered code not valid

## Teleloading of a programming file

- LOAD** Access to the teleloading of programming files sub-menu
- READ** Alternating with **CONS**: reading of the programming file stored in the  $\mu$ console
- COPY** Programming transfer
- $\mu$ Co** Indicates writing of the  $\mu$ C programming in progress to the  $\mu$ console (saving of a file)
- ← $\mu$ Co** Indicates teleloading of the  $\mu$ console programming file in progress to the  $\mu$ C (restoring of a file)
- ERR** **PROG** Programming file incorrect
- ERR** **OPT** File does not have the same options as the instrument currently in service

## Further functions

- INF** Minimum value display
- SUP** Maximum value display
- CLrM** Delete min. and max.
- CLrA** Delete recorded alarms.

## Error messages

- ERR1** Value set out of span
- OPEN** Sensor rupture
- 2000** Blinking measure: measure in overstepping
- OL** Displayable value overstepping
- Input upper or lower electrical overstepping
- ERxx** Self-diagnosis error
- ERR** **tYPE** **CONS** The  $\mu$ console type is not compatible with the converter type