


## ***F050-A***

***PRESSURE INDICATOR***



***Signal input sensor: (0)4-20mA***

***Options: Intrinsically Safe***



## SAFETY INSTRUCTIONS



- Any responsibility is lapsed if the instructions and procedures as described in this manual are not followed.
- **LIFE SUPPORT APPLICATIONS:** The F050-A is not designed for use in life support appliances, devices, or systems where malfunction of the product can reasonably be expected to result in a personal injury. Customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify the manufacturer and supplier for any damages resulting from such improper use or sale.
- Electro static discharge does inflict irreparable damage to electronics! Before installing or opening the F050-A, the installer has to discharge himself by touching a well-grounded object.
- The F050-A must be installed in accordance with the EMC guidelines (Electro Magnetic Compatibility).
- Connect a proper grounding to the metal enclosure as indicated if the F050-A has an incoming power or signal line which carries a hazardous live voltage. The Protective Earth (PE) wire may never be disconnected or removed.
- Intrinsically Safe applications: follow the instructions as mentioned in Chapter 5. Certificates and related documents are available on our website or from your distributor.

## DISPOSAL OF ELECTRONIC WASTE



- The WEEE Directive requires the recycling of disposed electrical and electronic equipment in the European Union. When the WEEE Directive does not apply to your region, we support its policy and ask you to be aware on how to dispose of this product.
- The crossed out wheeled bin symbol as illustrated and found on our products tells that this product shall not be disposed of into the general waste system or into a landfill.
- At the end of its life, equipment shall be disposed of according to the local regulations regarding waste of the electrical and the electronic equipment.
- Please contact your local dealer, national distributor or the manufacturer's Technical helpdesk for information on the product disposal.

## SAFETY RULES AND PRECAUTIONARY MEASURES

- The manufacturer accepts no responsibility whatsoever if the following safety rules and precautions, instructions and the procedures as described in this manual are not followed.
- Modifications of the F050-A implemented without preceding written consent from the manufacturer, will result in the immediate termination of product liability and warranty period.
- Mounting, electrical installation, start-up and maintenance of this device may only be carried out by trained persons authorized by the operator of the facility. Persons must read and understand this manual before carrying out its instructions.
- This device may only be operated by persons who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed.
- Check the mains voltage and information on the manufacturer's plate before installing the F050-A.
- Check all connections, settings and technical specifications of the various peripheral devices with the F050-A supplied.
- Open the enclosure only if all leads are free of potential.
- Never touch the electronic components (ESD sensitivity).
- Never expose the system to heavier conditions than allowed according to the classification of the enclosure (see manufacture's plate and chapter 4).
- If the operator detects errors or dangers, or disagrees with the safety precautions taken, he should inform the owner or principal responsible.
- The local labor and safety laws and regulations must be adhered to.

## ABOUT THE MANUAL

This operation manual is divided into two main sections:

- The daily use of the F050-A is described in chapter 2 "Operational". These instructions are meant for users.
- The following chapters and appendices are exclusively meant for electricians/technicians. These provide a detailed description of all software settings and hardware installation guidance.

This operation manual describes the standard F050-A as well as most of the options available. For additional information, please contact your supplier.

**A hazardous situation may occur if the F050-A is not used for the purpose it was designed for or is used incorrectly. Please carefully note the information in this operating manual indicated by the pictograms:**



A "**warning !**" indicates actions or procedures which, if not performed correctly, may lead to personal injury, a safety hazard or damage of the F050-A or connected instruments.



A "**caution !**" indicates actions or procedures which, if not performed correctly, may lead to personal injury or incorrect functioning of the F050-A or connected instruments.



A "**note !**" indicates actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned.

## WARRANTY AND TECHNICAL SUPPORT

For warranty and technical support for your Fluidwell products, visit our internet site [www.fluidwell.com](http://www.fluidwell.com) or contact us at [support@fluidwell.com](mailto:support@fluidwell.com).

Hardware version : 03.03.xx  
 Software version : 03.03.xx  
 Manual : FW-F050-A-M\_v0404\_01\_EN.docx  
 © Copyright 2022 : Fluidwell B.V. - the Netherlands

**Information in this manual is subject to change without prior notice. The manufacturer is not responsible for mistakes in this material or for incidental damage caused as a direct or indirect result of the delivery, performance or use of this material.**

**© All rights reserved. No parts of this publication may be reproduced or used in any form or by any means without written permission of your supplier.**

# CONTENTS MANUAL

<b>SAFETY INSTRUCTIONS.....</b>	<b>2</b>
<b>DISPOSAL OF ELECTRONIC WASTE .....</b>	<b>2</b>
<b>SAFETY RULES AND PRECAUTIONARY MEASURES .....</b>	<b>2</b>
<b>ABOUT THE MANUAL .....</b>	<b>3</b>
<b>WARRANTY AND TECHNICAL SUPPORT.....</b>	<b>3</b>
<b>CONTENTS MANUAL .....</b>	<b>4</b>
<b>1 INTRODUCTION .....</b>	<b>6</b>
1.1 System description of the F050-A.....	6
<b>2 OPERATIONAL.....</b>	<b>7</b>
2.1 General information .....	7
2.2 Control panel.....	7
2.3 Operator information and functions .....	7
<b>3 CONFIGURATION.....</b>	<b>9</b>
3.1 Introduction .....	9
3.2 Programming SETUP-level.....	9
3.2.1 Entering SETUP-level .....	9
3.2.2 Navigating through SETUP-level .....	9
3.2.3 Programming sequence.....	10
3.2.4 Returning to OPERATOR-level .....	11
3.3 Configuration Settings.....	12
3.3.1 Overview functions SETUP level .....	12
3.3.2 Explanation of SETUP-menu 1 - Pressure .....	13
3.3.3 Explanation of SETUP-menu 2 - Display.....	13
3.3.4 Explanation of SETUP-menu 3 - Power management .....	14
3.3.5 Explanation of SETUP-menu 4 - Sensor .....	14
3.3.6 Explanation of SETUP-menu 5 - Others.....	15
<b>4 INSTALLATION.....</b>	<b>16</b>
4.1 General directions.....	16
4.2 Installation / surrounding conditions .....	16
4.3 Handling the F-Series enclosure .....	17
4.3.1 Identification.....	17
4.3.2 Opening / Removing the cover .....	19
4.3.3 Closing / Replacing the cover .....	19
4.4 Mechanical installation.....	20
4.4.1 Dimensions – Aluminum and stainless steel enclosures .....	20
4.4.2 Dimensions – Non-metallic enclosures.....	21
4.4.3 Mounting .....	22
4.5 Electrical installation .....	23
4.5.1 Electrical safety.....	23
4.5.2 Protective Earth (PE) connections.....	23
4.5.3 Field wiring connections.....	24
4.5.4 Power supply wiring.....	25
4.5.5 Sensor supply .....	25
4.6 Terminal connectors safe area applications – Type PB / PD / PL / PX.....	26
4.6.1 Terminals 1-2: Sensor input.....	26
4.6.2 Terminal 4-5: Power supply - type PX (default) and PD (option) .....	27
4.6.3 Terminal 9-10: Power supply backlight - type ZB (option).....	27
4.7 Terminal connectors safe area applications – Type PF / PM .....	27
4.7.1 Terminal GND-1-2: Power Supply .....	27
4.7.2 Terminals 5-7: Sensor input.....	28
<b>5 INTRINSICALLY SAFE APPLICATIONS .....</b>	<b>29</b>
5.1 Identification.....	29
5.2 Electrical installation in hazardous area .....	30
5.2.1 General information and instructions .....	30
5.2.2 Installations based on FM or CSA certificate .....	30
5.2.3 Electrical data – Control drawing .....	31
5.2.4 Installations based on ATEX or IECEx certificate.....	33
5.2.5 Electrical data – Annex 1 .....	34
5.3 Terminal connectors Intrinsically Safe applications .....	35

5.3.1	Power supply wiring.....	35
5.3.2	Terminal 6 - Type PD: Sensor supply .....	35
5.4	Configuration examples Intrinsically Safe applications .....	36
5.4.1	F050-A-PX-XI-ZB - Ex ia IIC/IIIC .....	36
5.4.2	F050-A-PD-XI-ZB - Ex ia IIC/IIIC .....	36
5.4.3	F050-A-PL-XI-ZB - Ex ia IIC/IIIC .....	37
<b>6</b>	<b>MAINTENANCE .....</b>	<b>38</b>
6.1	General directions .....	38
6.2	Instructions for repair.....	38
6.3	Battery replacement .....	39
6.3.1	Safety instructions .....	39
6.3.2	Replace the battery .....	40
6.3.3	Disposal of batteries .....	40
	<b>APPENDIX A. TECHNICAL SPECIFICATION .....</b>	<b>41</b>
	<b>APPENDIX B. PROBLEM SOLVING .....</b>	<b>44</b>
	<b>APPENDIX C. DECLARATION OF CONFORMITY .....</b>	<b>45</b>
	<b>INDEX OF THIS MANUAL.....</b>	<b>46</b>
	<b>LIST OF FIGURES.....</b>	<b>47</b>

# 1 INTRODUCTION

## 1.1 SYSTEM DESCRIPTION OF THE F050-A

### Functions and features

The pressure indicator model F050-A is a microprocessor driven instrument designed to display the pressure.

This product has been designed with a focus on:


- ultra-low power consumption to allow long-life battery powered applications (type PB / PC),
- intrinsic safety for use in hazardous applications (type XI),
- several mounting possibilities with GRP, aluminum or stainless steel 316L enclosures for industrial surroundings,
- ability to process all types of sensor signals.

### Sensor input

This manual describes the unit with an analog (0)4-20mA input type from the sensor "-A version".

Other versions are available to process 0-10V sensor signals.

One sensor with a passive or active (0)4-20mA signal output can be connected to the F050-A. To power the sensor, several options are available.



**Fig. 1: Typical application for the F050-A.**

### Configuration of the F050-A

The F050-A has been designed to be implemented in many types of applications. For that reason, a SETUP-level is available to configure your F050-A according to your specific requirements.

It includes several important features, such as span, measurement units, display options etc. All settings are stored in EEPROM memory and will not be lost in the event of power failure. To extend the battery-life time, please use of the power-management functions as described in chapter 3.3.4.

### Display information

The F050-A has a large transfective LCD with all kinds of symbols and digits to display measuring units, status information, trend-indication and key-word messages.

Pressure values are displayed with the large 26mm (1") digits while the smaller 8mm (0.31") digits will display the measuring unit.

The Piegraph is percentage-wise related to the span.

### Options

The following options are available: intrinsic safety, power- and sensor-supply options, panel-mount, wall-mount and weather-proof enclosures, flame proof enclosure and LED backlight.

## 2 OPERATIONAL

### 2.1 GENERAL INFORMATION

This chapter describes the daily use of the F050-A. This instruction is meant for users / operators.



Caution !

- The F050-A may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed
- Take careful notice of the "Safety rules, instructions and precautionary measures" in the front of this manual.

### 2.2 CONTROL PANEL

The control panel has three keys. The following keys are available:



Fig. 2: Control panel.

#### Functions of the keys



##### **PROG-key**

This key is used to program and save new values or settings.  
The PROG-key is also used to gain access to SETUP-level; please read chapter 3.



##### **SELECT-key**

This key is used to SELECT the displayed information.



##### **CLEAR-key**

This key is used to CLEAR the value of total.

### 2.3 OPERATOR INFORMATION AND FUNCTIONS

In general, the F050-A will always function at Operator level. The information displayed is dependent upon the SETUP-settings. The signal from the connected sensor is processed by the F050-A in the background, whichever screen refresh rate setting is chosen. After pressing a key, the display will be updated very quickly during a 30 second period, after which it will slow-down again.



Fig. 3: Example of display information during process.

**For the Operator, the following functions are available:**

- **Display pressure**

This is the main display information of the F050-A. After selecting any other information, it will always return to this main display automatically.  
Pressure is displayed on the upper-line of the display and the measuring unit on the bottom line.  
When "-----" is shown, then the value is too high to be displayed.

- **Piegraph indication**

This 10 segment Piegraph gives a quick impression about the actual value in relation to its measuring range in a scale of 0-100%.

- **Low-battery alarm**

When the battery voltage drops, it must be replaced. At first "battery low" will flash, but as soon as it is displayed continuously, the battery **MUST** be replaced shortly after!

The remaining lifetime after the first moment of indication is generally several days up to some weeks. See paragraph 6.3 for further information on battery replacement.



**Fig. 4: Example of low-battery alarm.**

- **Range error**

As soon as the input value is 5% outside the calibrated measurement range, the piegraph starts flashing. Meanwhile, LO CURRENT or HI CURRENT will be displayed.

- **Alarm 01-03**

When "alarm" is displayed, please consult Appendix B: problem solving.



## 3 CONFIGURATION

### 3.1 INTRODUCTION

This and the following chapters are exclusively meant for electricians and non-operators. In these, an extensive description of all software settings and hardware connections are provided.



- Mounting, electrical installation, start-up and maintenance of the instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must read and understand this Operating Manual before carrying out its instructions.
- The F050-A may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed.
- Ensure that the measuring system is correctly wired up according to the wiring diagrams. The housing may only be opened by trained personnel.
- Take careful notice of the "Safety rules, instructions and precautionary measures" in the front of this manual.

### 3.2 PROGRAMMING SETUP-LEVEL



*Changing the settings of the F050-A may have an influence on the current operation of the device, even when SETUP-level is still active.  
Make sure that the unit is not being used for any application when altering the settings.*

#### 3.2.1 ENTERING SETUP-LEVEL

Configuration of the F050-A is done at SETUP-level, which can be reached at all times while the F050-A remains fully operational. At SETUP-level the display will deactivate the **RUN** indicator and activate the **SETUP** indicator.

**Use the control panel to access SETUP-level**



**PROG-key**

To enter SETUP-level, press the PROG-key for 7 seconds at OPERATOR-level. During this time, the symbols ▲ ▼ will be displayed.


When SETUP-level is entered, a password might be required to continue. You can enter the password by following the procedure for programming values as described in the following paragraphs.



*A password may be required to enter SETUP.  
Without this password access to SETUP is denied.*

#### 3.2.2 NAVIGATING THROUGH SETUP-LEVEL

Each function has a unique menu-number, which is displayed near the **SETUP** indicator at the bottom of the display. The menu-number is a combination of two figures, e.g. 1.2. The first number indicates the function-group and the second number indicates the function. Additionally, each function and function-group is expressed with a keyword.



**Fig. 5: SETUP matrix structure**

### Use the control panel to navigate through SETUP-level



#### PROG-key

When a function is selected, this key is used to start the programming sequence.  
When only a function group is selected (and no function), this key is used to scroll back a function group (e.g. 3 → 2 → 1 → 3).



#### SELECT-key

This key is used to select the next function in the list (e.g. 1 → 1.1 → 1.2 → 1). When the top of the list is reached, it will wrap around and return to the function group selection.



#### CLEAR-key

This key is used to select the previous function in the list (e.g. 1.2 → 1.1 → 1 → 2).  
When the bottom of the list is reached, it will return to the function group selection.  
When only a function group is selected (and no function), this key is used to scroll to the next function group. (e.g. 1 → 2 → 3 → 1).

### 3.2.3 PROGRAMMING SEQUENCE

After selecting a function at SETUP-level, a new value can be programmed using the control panel. A function either contains a value (a number with optionally a decimal point, e.g. 123.45) or a list with items (e.g. Disable – Enable).

For each function that needs to change, navigate to that function and follow the steps indicated below. During the programming sequence, the display will deactivate the **SETUP** indicator and activate the **PROGRAM** indicator.



Note !

*When programming new values, alterations will only be set after the PROG-key has been pressed to confirm the new value! (STEP 3)*

#### Step 1: Starting the programming sequence



#### PROG-key

When a function is selected at SETUP-level, this key is used to start the programming sequence.

#### Step 2a: Changing a value




#### SELECT-key

This key is used to increment the selected digit.  
When the entered value is out of range, the increase sign ▲ or decrease-sign ▼ will be displayed while you are programming. If this value is confirmed by pressing the PROG-key, the value will be brought within a valid range automatically.



#### CLEAR-key

This key is used to select the next digit. If a decimal point can be set, this will be included in the sequence as well (e.g. [decimal point] → digit 1 → digit 2 → digit 3 → [decimal point]).



#### SELECT-key + CLEAR-key

The combination of the SELECT-key and CLEAR-key is used to select a negative value. When a value can also be entered as a negative number, pressing the SELECT-key and CLEAR-key simultaneously will toggle the '–' (minus) sign on and off.

**Step 2b: Changing the selected item in a list****SELECT-key**

This key is used to select the next item in the list (e.g. Disable → Enable).  
At the end of the list, the selection will wrap around to the first selection.

**CLEAR-key**

This key is used to select the previous item in the list (e.g. Enable → Disable ).  
At the bottom of the list, the selection will wrap around to the last selection.

**Step 3: Finishing the programming sequence****PROG-key**

During the programming sequence, this key is used to confirm the new value and return to SETUP-level. To cancel the operation, either press the PROG-key for 3 seconds or wait for 20 seconds: the programming sequence is cancelled and the former value is reinstated.

**3.2.4 RETURNING TO OPERATOR-LEVEL**

When all settings are configured correctly, the unit can be returned to OPERATE-level.  
Please keep a record of all settings for later reference.

**Use the control panel to return to OPERATE-level****PROG-key**

In order to return to the operator level, press the PROG-key for three seconds.  
When no keys are pressed for 2 minutes, SETUP-level will be left automatically.

### 3.3 CONFIGURATION SETTINGS

All settings of the F050-A can be set via the control panel.

The following paragraphs give a detailed description of each setting.


#### 3.3.1 OVERVIEW FUNCTIONS SETUP LEVEL

SETUP FUNCTIONS AND VARIABLES			
<b>1</b>	<b>PRESSURE</b>		
	1.1	UNIT	mbar - bar - PSI - mPA - PA - no unit
	1.2	DECIMALS	0 - 1 - 2 - 3 - 4 - 5 (Ref: displayed value)
	1.3	SPAN	0.00001 - 199,999 unit
	1.4	OFFSET	-99,999 to +199,999 unit
<b>2</b>	<b>DISPLAY</b>		
	2.1	BARGRAPH	off - on
	2.2	BACKLIGHT (optional)	off - on
	2.3	BL. BRIGHTNESS (optional)	1 - 5
<b>3</b>	<b>POWER MANAGEMENT</b>		
	3.1	LCD UPDATE	fast - 1 sec - 3 sec - 15 sec - off
	3.2	BATTERY MODE	operational - shelf
<b>4</b>	<b>SENSOR</b>		
	4.1	FILTER	00 - 99
	4.2	CUT-OFF	0.0 - 99.9%
	4.3	CALIBRATE LOW	default - calibrate - calibrate set
	4.4	CALIBRATE HIGH	default - calibrate - calibrate set
<b>5</b>	<b>OTHERS</b>		
	5.1	TYPE / MODEL	F050-A
	5.2	SOFTWARE VERSION	03.xx.xx
	5.3	SERIAL NO.	xxxxxxx
	5.4	PASS CODE	0000 - 9999
	5.5	TAGNUMBER	0000000 - 9999999

### 3.3.2 EXPLANATION OF SETUP-MENU 1 - PRESSURE


SETUP FUNCTIONS AND VARIABLES		
1	PRESSURE	
1.1	MEASUREMENT UNIT	<p>SETUP 1.1 determines the measurement unit for the displayed pressure. The following units can be selected:</p> <p style="text-align: center;">mbar - bar - PSI - mPA - PA - _ (no unit).</p> <p>Alteration of the measurement unit will have consequences for operator and SETUP-level values. Please note that the span has to be adapted as well; the calculation is not done automatically.</p>
1.2	DECIMALS	<p>This setting determines for displayed pressure the number of digits following the decimal point. The following can be selected:</p> <p style="text-align: center;">00000 - 1111.1 - 222.22 - 33.333</p>
1.3	SPAN	<p>With the span, the sensor signal is converted to a displayed pressure. The span is determined on the basis of the selected measuring range of the sensor. The more accurate the span, the more accurate the functioning of the system will be.</p> <p><b>Example                      Calculating the span</b> Let us assume that the sensor generates 20mA at 18.95 bar and the selected unit is mbar. The span is thus 18.950 mbar. Enter for SETUP 1.3: "18.950".</p>
1.4	OFFSET	<p>Enter the minimum pressure at which the sensor starts to generate a signal of (0)4mA. A minus sign can be set by pressing the center and right button simultaneously.</p>

### 3.3.3 EXPLANATION OF SETUP-MENU 2 - DISPLAY

SETUP FUNCTIONS AND VARIABLES		
2	DISPLAY	
2.1	BARGRAPH	<p>The bargraph (piegraph) displayed at operator level is percentage-wise related to the input signal: minimum signal is 0% (SETUP 4.3) and maximum signal is 100% (SETUP 4.4). With this function, the bargraph can be enabled / disabled. Following selections are available:</p> <p style="text-align: center;">OFF - ON</p>
		<p style="text-align: center;"> Note !</p> <p><i>The functions below will only affect the optional LED-backlight.</i></p>
2.2	BACKLIGHT (optional)	<p>If a LED backlight has been supplied, it can be turned on or off.</p>
2.3	BL. BRIGHTNESS (optional)	<p>The backlight brightness is adjustable. The following can be selected: 1 – 5 (where 1 is minimum and 5 is maximum brightness)</p>



### 3.3.4 EXPLANATION OF SETUP-MENU 3 - POWER MANAGEMENT

When used with the internal battery option, the user can expect reliable measurement over a long period of time. The F050-A has several smart power management functions to extend the battery life time significantly. Two of these functions are available.

SETUP FUNCTIONS AND VARIABLES		
3	POWER MANAGEMENT	
3.1	LCD NEW	<p>The calculation of the display-information influences the power consumption significantly. When the application does not require a fast display update, it is <b>strongly advised</b> to select a slow refresh rate. Please understand that NO information will be lost; every pulse will be counted and the output signal will be generated in the normal way. The following can be selected: Fast - 1 sec - 3 sec - 15 sec - off.</p> <p><b>Example battery life-time:</b></p> <ul style="list-style-type: none"> <li>FAST update: about 3 years.</li> <li>1 sec update: about 5 years.</li> </ul> <p> <b>Note !</b> After a button has been pressed by the operator - the display refresh rate will always switch to FAST for 30 seconds. When "OFF" is selected, the display will be switched off after 30 seconds and will be switched on as soon as a button has been pressed.</p>
3.2	BATTERY MODE	<p>The F050-A has two modes: operational or shelf. After "shelf" has been selected, the F050-A can be stored for several years; it will not process the sensor signal; the display is switched off but all settings and totals are stored. In this mode, power consumption is extremely low. To wake up the F050-A again, press the SELECT/▲ key twice.</p>

### 3.3.5 EXPLANATION OF SETUP-MENU 4 - SENSOR

SETUP FUNCTIONS AND VARIABLES					
4	SENSOR				
4.1	FILTER	The analog output signal of a sensor mirrors the actual pressure. This signal is measured several times per second by the F050-A. The value measured is a "snap-shot" of the real pressure as it will be fluctuating. With the help of this digital filter a stable and accurate reading can be obtained. The filter level can be set to a desired value. The filter is based on three input values: the filter level (01-99), the last measured analog value and the last average value. The higher the filter level, the longer the response time on a value change will be. Below, several filter levels with response times are indicated:			
	Filter value	Response time to step change in analog input value (seconds)			
		50%	75%	90%	99%
	01	filter disabled	filter disabled	filter disabled	filter disabled
	02	0.3	0.5	1.0	1.8
	03	0.5	1.0	1.5	3.0
	05	1.0	1.8	2.8	5.3
	10	1.8	3.5	5.6	11
	20	3.5	7.0	11	23
	30	5.3	10	17	34
	50	8.8	17	29	57
	75	13	26	43	86
	99	17	34	57	114

4.2	CUT-OFF	To ignore for instance vibrations in sensor output, a low-level cut-off can be set as percentage of the full range of 16mA (or 20mA). When the analog value is less than required with this setting, the signal will be ignored. The cut-off value can be programmed in the range 0.0 - 99.9%. Below an example is given.			
		Span (SETUP 1.3)	Required cut-off	Cut-off (SETUP 4.2)	Required output
		450 mbar	25 mbar	$(25/450)*100\%=5.5\%$	$16mA*5.5\%+4mA=4.88mA$
4.3	TUNE MIN / 4mA	With this setting it is possible to calibrate the input value for (0)4mA as the signal from the sensor might not be exact 4.0mA (or 0.0 mA) at the offset pressure. This function will measure the real output value at minimum pressure.			
		 <p>Note !</p> <p><i>The input loop powered version - type A-PL - requires a signal of at least 4mA; not lower!</i></p> <p><i>Be very sure that the offered signal is correct before calibration is executed, as this has major influence on the accuracy of the system</i></p> <p>After pressing PROG, three settings can be selected:</p> <ul style="list-style-type: none"> <li>CALIBRATE: with this setting, the input will be calibrated with the actual "(0)4mA" value. After pressing enter, CAL SET will be displayed as soon as the calibration is completed. From that moment, the analog value must be more than the calibrated value before the signal will be processed.</li> <li>DEFAULT: with this setting, the factory value is re-installed.</li> <li>CAL SET: to select the last calibrated value.</li> </ul>			
4.4	TUNE MAX / 20mA	With this setting it is possible to calibrate the input value for 20mA as the signal from the sensor might not be exact 20.0mA at maximum pressure (offset + span). This function will measure the real output value at maximum pressure.			
		 <p><i>Be very sure that the offered signal is correct before calibration is executed, as this has major influence on the accuracy of the system</i></p> <p>After pressing PROG, three settings can be selected:</p> <ul style="list-style-type: none"> <li>CALIBRATE: with this setting, the input will be calibrated with the actual "20mA" value. After pressing enter, CAL SET will be displayed as soon as the calibration is completed. From that moment, the analog value must be less than the calibrated value for reliable measurements.</li> <li>DEFAULT: with this setting, the factory value is re-installed.</li> <li>CAL SET: to select the last calibrated value.</li> </ul>			

### 3.3.6 EXPLANATION OF SETUP-MENU 5 - OTHERS

SETUP FUNCTIONS AND VARIABLES		
5	OTHERS	
5.1	TYPE / MODEL	For support and maintenance it is important to have information about the characteristics of the F050-A. Your supplier will ask for this information in the case of a serious breakdown or to assess the suitability of your model for upgrade considerations.
5.2	SOFTWARE VERSION	
5.3	SERIAL NO.	
5.4	PASS CODE	All SETUP-values can be pass code protected. This protection is disabled with value 0000 (zero). Up to and including 4 digits can be programmed, for example 1234.
5.5	TAGNUMBER	For identification of the F050-A and communication purposes, a unique tag number of maximum 7 digits can be entered.

## 4 INSTALLATION

### 4.1 GENERAL DIRECTIONS




Caution !

- Mounting, electrical installation, start-up and maintenance of this instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must read and understand this Operating Manual before carrying out its instructions.
- The F050-A may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed.
- Make sure that the measuring system is correctly wired up according to the wiring diagrams. Protection against accidental contact is no longer assured when the enclosure cover is removed or the panel cabinet has been opened (danger from electrical shock). The enclosure may only be opened by trained persons authorized by the operator of the facility.
- Take careful notice of the "Safety rules, instructions and precautionary measures" at the front of this manual.

The F0-Series can be supplied as suitable for Safe Area or Hazardous Area. This is indicated in the model code (shown on the product label) by the Type X\* designator, with following options:

- **Type XX:** Suitable for safe area applications only (e.g. F050-A-XX)  
Follow the mechanical and electrical installation instructions shown in chapter 4.
- **Type XF:** Suitable for explosion proof / flame proof applications (e.g. F050-A-XF)  
Follow the electrical installation instructions as shown in chapter 4 and the mechanical installation instructions of the enclosure that are supplied separately.
- **Type XI:** Suitable for intrinsically safe applications (e.g. F050-A-XI)  
Follow the *general* mechanical and electrical installation instructions of chapter 4 and the *specific* installation instructions of chapter 5.

### 4.2 INSTALLATION / SURROUNDING CONDITIONS



Take the relevant IP classification of the enclosure into account (see identification plate). Even an enclosure rated for IP67 / TYPE 4(X) should NEVER be exposed to strongly varying (weather) conditions.

When used in very cold surroundings or varying climatic conditions, inside the instrument case, take the necessary precautions against moisture.

Mount the F-Series onto a solid structure to avoid vibrations.

For use in Safe and Hazardous Areas (or Locations), the following conditions apply:

Relative humidity:	< 90% RH
Outdoor use:	suitable for outdoor use
IP and NEMA rating:	IP65 (panel mount), IP67 (field mount) and Type 4X
Supply voltage fluctuation:	As indicated by the supply range (e.g. 10V to 30V), otherwise +/- 10% unless stated otherwise
Means of protection:	Intrinsically safe: IS Ordinary locations: Class I (PE connected metal enclosure) Class II (non-metallic enclosure)
Over-voltage category:	II (when supplied from mains)
Pollution degree:	2 (internal environment), 3 (external environment)
Ambient:	Intrinsically safe: -40 °C to +70 °C, -40 °F to +158 °F (limited to +50 °C, 122 °F for EPL Da) Ordinary locations: -40 °C to +80 °C, -40 °F to +176 °F
Altitude:	up to 2000 m



### 4.3 HANDLING THE F-SERIES ENCLOSURE

#### 4.3.1 IDENTIFICATION



Note !

The F0-Series can be supplied as suitable for Safe Area or Hazardous Area. Suitability for Intrinsic Safety is indicated in the model code by Type XI (e.g. F050-A-XI).

For Intrinsically Safe applications: Installation and identification labels are shown in chapter 5.

#### Identification label

To identify your F0-Series device, all field mount enclosures have a weatherproof identification label placed on the outside of the unit.




Fig. 6: Identification – Example of F0-Series identification label (safe area)

#### Installation label

A second label is located on the inside and shows additional installation data. For panel mount enclosures, the outside label is not available, so the inside label also serves as identification label. After installation, the inside label is only visible from the rear side of the panel.




Fig. 7: Identification – Example of F0-Series installation label (safe area - Type PB, PX or PD)




Fig. 8: Identification – Example of F0-Series installation label (safe area - Type PM or PF))

### Serial number and year of production


The serial number can be reviewed on the identification label or in SETUP-menu Others. The production date is either shown separately on the label or indicated by the first 4 digits of the serial number representing year and week number (YYWW).



### 4.3.2 OPENING / REMOVING THE COVER

To open the F-Series enclosure, the front cover needs to be removed. Please follow this procedure:

1. If necessary, clean the enclosure with an anti-static cloth made damp with a mild soap solution. Wait for the enclosure to dry before opening.
2. While loosening the screws, hold on to the front cover to prevent it from falling down.
3. Unscrew all 4 screws from the front of the enclosure and (if present) mind that the serrated washers are kept with the screws.
4. Carefully take the front cover away from the rear cover, minding that the wiring stays intact.
5. Depending on the work to be done, all terminal connectors can be removed from their mating parts and the front cover is now completely separate.



### 4.3.3 CLOSING / REPLACING THE COVER

To replace the cover on the F-Series enclosure, follow this procedure:

1. Re-insert all terminals to their original position.
2. Carefully position the front cover onto the back cover, making sure that the gasket falls nicely into the gutter of the back cover.
3. Replace all 4 screws into the front cover and mind that the serrated washers are replaced (metal enclosure only).
4. Fasten all 4 screws in an alternating way so that the front cover is placed evenly across the edge of the back cover.

Tighten the 4 screws with the torque value for the type of enclosure as specified in following table:

Plastic enclosure:	1 Nm per screw
Aluminum enclosure:	1 Nm per screw
Aluminum w. extended back enclosure:	1 Nm per screw
Stainless steel enclosure:	2 Nm per screw

5. The F-Series is now ready to be returned to service.



## 4.4 MECHANICAL INSTALLATION

### 4.4.1 DIMENSIONS – ALUMINUM AND STAINLESS STEEL ENCLOSURES



Note !

- When ordering stainless steel enclosures, insert S after H, e.g. HA → HSA).
- Aluminium enclosures are available with a 15 mm/0.6" deeper rear cover (insert B after H: HBx).




Fig. 9: Dimensions – Aluminum and stainless steel enclosures

#### 4.4.2 DIMENSIONS – NON-METALLIC ENCLOSURES







Fig. 10: Dimensions – Non-metallic enclosures


#### 4.4.3 MOUNTING

The enclosure can be installed by itself or with the aid of a mounting plate in the configurations shown below. When the unit is installed on a wall or onto a meter, please use components and installation techniques that are suitable for the used materials.


When using the mounting plate, please follow the instructions that came with the accessories. Alternatively, the unit can be panel mounted by using only the front cover.




*Wall mount by using the openings on the (out)side of the back cover.*





*Wall mount by using the mounting plate (accessory)*



*Meter mount by using one of the openings in the bottom of the back cover.*



*Pipe mount by using the mounting plate with the bracket and hose clamps (accessory).*



*Panel mount by using only the front cover*

**Fig. 11: Installation – Mounting configurations**

## 4.5 ELECTRICAL INSTALLATION



- Electro static discharge does inflict irreparable damage to electronics! Before installing or opening the F050-A, the installer has to discharge himself by touching a well-grounded object.
- For reasons of ESD and safety, always ground the metal enclosure properly as indicated, especially if the unit has been supplied with the 115-230V AC power-supply type PM or relays type OR. It is the responsibility of the installer to install, connect and test the Protective Earth connections in accordance with the (inter)national Rules and Regulations.
- This chapter shows general information regarding the electrical installation of the F050-A. Chapter 5 gives additional specific information regarding Intrinsically safe installation and overrules the information given in this chapter.



- Do not combine metal front covers with non-metallic rear covers, vice versa and / or cable glands. A metal cover on a non-metallic rear cover could lead to ESD. A metal cable gland in a non-metallic enclosure could invalidate isolation.
- The installation must comply with (inter)national requirements and local ordinances.
  - Within the European Union and the UK, all installations must comply with national regulations.
  - Within Canada all field wiring must conform to Section 18-156 of the Canadian Electrical Code for installations within Canada.
  - Within the United States all field wiring must conform to the National Electric Code, NFPA 70, Article 501-4(b).

### 4.5.1 ELECTRICAL SAFETY

Please consult the table with environmental conditions and safety parameters shown at the beginning of this chapter.

#### General directions:

- The F050-A that came with a power module type PM; 110V-230V AC or type PD/PF with an option OR (the relays can handle 110V-230V AC) shall be connected to the Protective Earth (PE) stud which is installed in the metal back panel. The metal front panel is connected to the Protective Earth by the mounting screws and serrated washers.
- The wire screens (shield) are meant to prevent electromagnetic interference and shall be connected to the common ground terminals that belong to the specific sensor connection. The wire screens shall be terminated at one side to prevent wire loops. Inside of the Fluidwell unit, the different common ground terminals are connected to each other. It is advised, as illustrated, to terminate the wire screens in the vicinity of the sensor and to insulated the wire screen with a shrink tube at the Fluidwell unit side.
- Separate cable glands with effective IP67 / TYPE 4(X) seals for all wires.
- Unused cable entries: ensure that you fit IP67 / TYPE 4(X) plugs to maintain rating.
- A reliable ground connection for both the sensor, and if applicable, for the metal enclosure.
- An effective screened cable for the input signal, and grounding of its screen to the “⊥” terminal or at the sensor itself, whichever is appropriate to the application.

### 4.5.2 PROTECTIVE EARTH (PE) CONNECTIONS

Inside the unit, different types of bonding and earthing are used. The common ground is mostly used for termination of the wire shields; the Protective Earth (PE) is used for electrical safety.

For externally powered installations, route the Protective Earth (PE) grounding conductor into the enclosure together with the incoming power conductors.



#### Risk of damage to equipment!

Be very careful when connecting the common ground of the system to Protective Earth (PE). Connecting the common ground to Protective Earth (PE) (especially when multiple power supplies are connected) can cause ground loop currents that could damage the equipment.


#### Metal enclosure

When the F050-A is supplied with a metal enclosure (aluminum or stainless steel), the enclosure must be grounded in accordance with national and local electrical codes.

To ground the field mounted unit, the PE conductor must be connected to the PE stud which is located in the metal back cover, as indicated in the image below. To connect the conductor, a screw



(M4 x 6mm) with a serrated washer, a terminal and a washer is used (torque: 2 Nm). The metal front cover is connected to the Protective Earth by the mounting screws with serrated washers. To ground the panel mounted unit, the PE conductor must be connected to the metal front cover through one of the four mounting screws. For this purpose, an additional nut, terminal and washer is supplied.



**Fig. 12: Protective Earth (PE) connections on metal enclosure**

#### Plastic enclosure

When the F050-A is supplied with a non-metal enclosure (e.g. plastic), the field mount enclosure meets the requirements of class 2 (double insulated). Therefore any incoming PE conductor can be terminated with an insulating end cap.

When the F050-A is panel mounted, the installation class and protective earth requirements depend on the panel or type of cabinet.

#### 4.5.3 FIELD WIRING CONNECTIONS



- Do ground the aluminum / stainless steel enclosure properly with a PE wire as indicated to the Protective Earth terminal. It is the responsibility of the installer to install, connect and test the Protective Earth connections in accordance with the local and (inter)national Rules and Regulations.
- When a power supply is connected to the field wiring connections, please also consider the demands for power supply wiring shown in paragraph 4.5.4.
- The installation must comply with (inter)national requirements and local ordinances.
  - Within the Europe Union and the UK, all installations must comply with national regulations.
  - Within Canada all field wiring must conform to Section 18-156 of the Canadian Electrical Code for installations within Canada.
  - Within the United States all field wiring must conform to the National Electric Code, NFPA 70, Article 501-4(b).

All field wiring enters the F050-A through the bottom of the enclosure and connects to the circuit assembly inside the enclosure. Wiring is routed through cable glands. Please make sure to order the F050-A with the correct drilling pattern and thread (metal) or hole (plastic) sizes.

The wire screens (shield) are meant to prevent electromagnetic interference and shall be terminated at one side to prevent ground loops. Connection of the screen can either be made to the common ground terminal or at the sensor itself, whichever is appropriate to the application. Inside of the Fluidwell unit, the various common ground terminals are connected to each other. It is advised to terminate the wire screens in the vicinity of the sensor and to insulate the wire screen with a shrink tube at the F050-A side.



#### 4.5.4 POWER SUPPLY WIRING



When not directly supplied from mains (type PM), the external power supply must be an approved ELV source, insulated from AC mains by double / reinforced insulation per CSA C22.2 No. 61010-1 / UL61010-1 / EN/IEC 61010-1.

The F050-A can be powered from an external power supply. An internal power supply is also available in the form of a lithium battery. When both external and internal power supplies are available, the internal power supply is interrupted and will act as a backup supply. Note that the optional backlight only works with an external power supply.

#### 4.5.5 SENSOR SUPPLY

##### For type PD - Terminal 6: sensor supply

Type PD offers a sensor supply on terminal 6, with the same voltage as the supply connected to terminal 5.

##### For type PF / PM – Terminal 7: sensor supply, 8.2V, 12V or 24V

Type PF and PM offer a power supply for the sensor. The sensor can be externally powered with 8.2V, 12V or 24V DC (max. 400mA @24V). The voltage is selected with the three switches inside the F050-A.



- Be sure that all the leads to the terminals are disconnected from the F050-A when the internal plastic protection cover has been removed !
- **HIGH VOLTAGE 400V !!**  
NEVER connect the mains power supply to the F050-A when the plastic protection cover has been removed !!!

To gain access to the switches, first remove the terminal strip(s) after which the internal plastic cover can be removed. The switches are located on the right hand side as indicated:

Voltage selection for Type PF and Type PM																									
		<b>Power supply input:</b> Type PF: 24V AC / DC Type PM: 115V - 230V AC <b>Sensor supply output:</b> Max 400mA @ 24V DC																							
		<table border="1"> <thead> <tr> <th rowspan="2">Sensor power</th> <th colspan="3">Switch</th> </tr> <tr> <th>J1</th> <th>J2</th> <th>J3</th> </tr> </thead> <tbody> <tr> <td>1.2 / 3.2V DC</td> <td>on</td> <td>on</td> <td>on</td> </tr> <tr> <td>8.2V DC</td> <td>off</td> <td>on</td> <td>on</td> </tr> <tr> <td>12V DC</td> <td>off</td> <td>on</td> <td>off</td> </tr> <tr> <td>24V DC</td> <td>off</td> <td>off</td> <td>off</td> </tr> </tbody> </table>	Sensor power	Switch			J1	J2	J3	1.2 / 3.2V DC	on	on	on	8.2V DC	off	on	on	12V DC	off	on	off	24V DC	off	off	off
Sensor power	Switch																								
	J1	J2	J3																						
1.2 / 3.2V DC	on	on	on																						
8.2V DC	off	on	on																						
12V DC	off	on	off																						
24V DC	off	off	off																						

Fig. 13: Switch position voltage selection (type PF and PM).

#### 4.6 TERMINAL CONNECTORS SAFE AREA APPLICATIONS – TYPE PB / PD / PL / PX



Take careful notice of all safety and precautionary measures indicated in paragraph 4.5: Electrical Installation and review paragraph 4.5.3 and 4.5.4 before applying any field or power supply wiring.



Caution !

For Intrinsically Safe applications: read chapter 5.

Following terminal connectors are available on the F050-A Type PB / PD/ PL / PX:




Fig. 14: Overview of terminal connectors F050-A – type PB / PD / PL / PX

##### 4.6.1 TERMINALS 1-2: SENSOR INPUT

The F050-A requires a (0)4-20mA sensor signal which will be processed 4 times a second with a 16 bits accuracy. The input is not isolated.

The screen of the signal wire can be connected to the common ground terminal. See paragraph 4.5.3.

##### Type PL: input loop power

Model F050-A-PL is powered from the 4-20mA sensor signal.




Fig. 15: Terminal connections - Analog signal input.

#### 4.6.2 TERMINAL 4-5: POWER SUPPLY - TYPE PX (DEFAULT) AND PD (OPTION)

To power the F050-A an internal battery can be used (type PB) and / or an external DC power supply of 8-30V DC (type PX) or 16-30V DC (type PD). Connect the "-" to terminal 4 and the "+" to terminal 5.

When power is applied to these terminals, the optional internal battery will be disabled / enabled automatically to extend the battery life time.

#### 4.6.3 TERMINAL 9-10: POWER SUPPLY BACKLIGHT - TYPE ZB (OPTION)

To power the backlight, a voltage in the range 20-30V DC has to be connected.

Maximum current 30mA. Connect the "-" to terminal 9 and the "+" to terminal 10.




Fig. 16: Terminal connections - Backlight (ZB).

#### 4.7 TERMINAL CONNECTORS SAFE AREA APPLICATIONS – TYPE PF / PM



Take careful notice of all safety and precautionary measures indicated in paragraph 4.5: Electrical Installation and review paragraph 4.5.3 and 4.5.4 before applying any field or power supply wiring.



Caution !

For Intrinsically Safe applications: read chapter 5.

Following terminal connectors are available on the F050-A when supplied with Type PF / PM:

POWER SUPPLY TYPE: PF / PM								SENSOR SIGNAL TYPE: A ANALOG (0)4-20mA		
GND ⊥	1 N	2 L1						5 ⊥	6 I ↑	7 + ↓

Fig. 17: Overview of terminal connectors F050-A – type PF / PM

##### 4.7.1 TERMINAL GND-1-2: POWER SUPPLY

To power the F050-A with a power supply option of type PF or type PM, connect a suitable power supply to the terminals as indicated in below table:

Power supply option	Power supply	Terminal		
		GND	01	02
Type PF	24V AC $\pm$ 10%		AC	AC
Type PF	24V DC $\pm$ 10%	L-	L+	
Type PM	115-230V AC $\pm$ 10%		AC	AC
Note ! The total consumption of the sensor and backlight type ZB may not exceed 400mA @24V DC.				



### Risk of damage to equipment!

Be very careful when connecting the common ground of the system to Protective Earth (PE). Connecting the common ground to Protective Earth (PE) (especially when multiple power supplies are connected) can cause ground loop currents that could damage the equipment. See paragraph 4.5.2: Protective Earth (PE) connections for more information.

#### 4.7.2 TERMINALS 5-7: SENSOR INPUT

The F050-A requires a (0)4-20mA sensor signal which will be processed 4 times a second with a 16 bit accuracy. The input is not isolated.

The screen of the signal wire can be connected to the common ground terminal. See paragraph 4.5.3.




Fig. 18: Terminal connections - Analog signal input.

## 5 INTRINSICALLY SAFE APPLICATIONS

### 5.1 IDENTIFICATION



The F0-Series can be supplied as suitable for Safe Area or Hazardous Area. Suitability for Intrinsic Safety is indicated in the model code by Type XI (e.g. F050-A-XI).

**If Type XI is not indicated your device is not suitable for Intrinsically Safe applications!**

#### Identification label

To identify your F0-Series device, all field mount enclosures have a weatherproof identification label placed on the outside of the unit.




Fig. 19: Identification – Example of F0-Series identification label (intrinsic safety)

#### Installation label

A second label is located on the inside and shows additional installation data. For panel mount enclosures, the outside label is not available, so the inside label also serves as identification label. After installation, the inside label is only visible from the rear side of the panel.




Fig. 20: Identification – Example of F0-Series installation label (intrinsic safety)

## 5.2 ELECTRICAL INSTALLATION IN HAZARDOUS AREA

### 5.2.1 GENERAL INFORMATION AND INSTRUCTIONS



Caution !

#### Cautions

- Mounting, electrical installation, start-up and maintenance of this device may only be carried out by trained persons authorized by the operator of the facility. Persons must read and understand this manual before carrying out its instructions.
- This device may only be operated by persons who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed.
- Make sure the measuring system is correctly wired up according to the wiring diagrams. Protection against accidental contact is no longer assured when the enclosure cover is removed or the panel cabinet is opened (danger from electrical shock). The enclosure may only be opened by trained persons authorized by the operator of the facility.
- To maintain the degree of protection of at least IP65 in accordance with IEC 60529, suitable cable entries and blanking elements must be used and correctly installed.
- Take careful notice of the "Safety rules, instructions and precautionary measures" in the front of this manual.
- Chapter 4 shows general information regarding the electrical installation of your indicator. This chapter gives additional specific information regarding Intrinsically safe installation and overrules the information given in chapter 4.
- When installing this device in hazardous areas, the wiring and installation must comply with the appropriate installation standards for your industry.



#### Safety instructions

- For the combined connection of the different supply, input and output circuits, the instructions in this manual must be observed.
- Precautions shall be taken to avoid the risk of electrostatic discharge (ESD) and propagating brush discharges.
- For reasons of ESD and safety, always ground the metal enclosure properly as indicated in section "4.5. Electrical installation" of this manual.
- Do not blend metal front covers with non-metallic rear covers, vice versa and / or cable glands. A metal cover on a non-metallic rear cover could lead to ESD. A metal cable gland in a non-metallic enclosure could invalidate isolation.
- For enclosures and windows with a high surface resistance, potential charging hazard exists. Do not rub these surfaces of the indicator. Clean window and enclosure only with a lint-free cleaning cloth made damp with a mild soap solution.



Note !

#### Please note

- Certificates and related documents are available on our website or from your distributor.
- Carefully study the configuration examples with wiring diagrams per classification in the following paragraphs.

### 5.2.2 INSTALLATIONS BASED ON FM OR CSA CERTIFICATE



#### Installation instructions

- For installation in the **US**: this Intrinsically Safe device must be installed in accordance with the National Electrical Code, NFPA 70, Article 504 and ANSI/ISA-RP 12.6 and product certificate FM16US0177X or CSA.08.2059461.
- For installation in **Canada**: this Intrinsically Safe device must be installed in accordance with the Canadian Electrical Code, Part 1 Appendix F and product certificate CSA.08.2059461.

#### Covered markings

- Intrinsically Safe for Class I/II/III, Division 1, Groups A,B,C,D,E,F,G, Temperature class T4
- Class I, Zone 0, AEX ia IIC T4

#### Safety instructions


- Please consult the control drawing for this F0-Series model on the following page.
- Read paragraph 6.3 for battery replacement instructions.

#### Specific conditions of use

- When the enclosure of the indicator is made of aluminum alloy, when used in a potentially explosive atmosphere requiring apparatus of equipment protection level Ga, the indicator shall be installed so, that even in the event of rare incidents, an ignition source due to impact or friction sparks between the enclosure and iron/steel is excluded.

## 5.2.3 ELECTRICAL DATA – CONTROL DRAWING

### Control Drawing F0xx-A-XI




- ♦ The installation must comply with national requirements (e.g. in Canada, the Canadian Electrical Code, Part 1 Appendix F and in USA, the National Electrical Code, NFPA 70, Article 504 and ANSI/ISA-RP 12.6).
- ♦ Warning: Substitution of components may impair intrinsic safety.
- ♦ For the circuits connected to terminals 1 and 2, 4 and 5, 7 and 8, 9 and 10, the output parameters of the connected barriers (up to 4) or hazardous location apparatus must meet the following requirements:
  - $V_{oc} \leq$  The lowest  $V_{max}$  of the CSA / FM Approved apparatus in the circuit
  - $I_{sc} \leq$  The lowest  $I_{max}$  of the CSA / FM Approved apparatus in the circuit
  - $P_{max} \leq$  The lowest  $P_{max}$  of the CSA / FM Approved apparatus in the circuit
  - $C_a \geq$  The sum of the cable capacitance and the internal capacitance  $C_i$  of each CSA / FM Approved apparatus installed in the circuit
  - $L_a \geq$  The sum of the cable inductance and the internal inductance  $L_i$  of each CSA / FM Approved apparatus installed in the circuit
- ♦ For the circuits connected to terminals 1 and 2, 4 and 6, 7 and 8, 11 and 12, the input parameters of the connected hazardous location apparatus must meet the following requirements:
  - $V_{max} \geq$  The  $V_{oc}$  of the of the circuit
  - $I_{max} \geq$  The  $I_{sc}$  of the circuit
  - $P_{max} \geq$  The  $P_{max}$  of the circuit
  - $C_i \leq$  The difference between the  $C_a$  of the circuit and the sum of the cable capacitance and the internal capacitance  $C_i$  of all other CSA / FM Approved apparatus installed in the circuit
  - $L_i \leq$  The difference between the  $L_a$  of the circuit and the sum of the cable inductance and the internal inductance  $L_i$  of all other CSA / FM Approved apparatus installed in the circuit
- ♦ Hazardous Location Apparatus – switches, thermocouples or non-inductive resistance devices, or CSA / FM – Certified Apparatus – should be connected in accordance with the manufacturer's installation instructions.
- ♦ The cable parameters are determined by the parameters of the system into which the F0-Series General Purpose Indicators is connected.
- ♦ Only certified Intrinsically Safe Fluidwell battery type FW-LiBat-0xx may be used and replaced in hazardous area.

**The entity parameters for F0-Series General Purpose Indicators, model F0xx-A-XI, are as follows:**

Terminals 1 and 2 – Input parameters:	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 150\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 0.92\text{ W}$	
Terminal 3 – Internally not connected		
Terminal 4 and 5 – Input parameters – Type -PD/-PX	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 200\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 1.2\text{ W}$	
Terminal 4 and 6 – Output parameters – Type -PD	$V_{oc}$ , $I_{sc}$ , $P_{max}$ , $C_a$ and $L_a$ are equal to those of the circuitry connected between terminals 4 and 5.	
Terminal 7 and 8 – Input parameters – Type -OT	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 200\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 1.2\text{ W}$	
Terminal 9 and 10 – Input parameters – Type -ZB	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 200\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 0.75\text{ W}$	
Terminal 11 and 12 – Input parameters – Type -AH	$V_{max} = 30\text{ V}$	$C_i = 6.1\text{ nF}$
	$I_{max} = 100\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 0.75\text{ W}$	

## Control Drawing F0xx-A-PL-XI



- ◆ The installation must comply with national requirements (e.g. in Canada, the Canadian Electrical Code, Part 1 Appendix F and in USA, the National Electrical Code, NFPA 70, Article 504 and ANSI/ISA-RP 12.6).
- ◆ Warning: Substitution of components may impair intrinsic safety.
- ◆ For the circuits connected to terminals 1 and 2, 4 and 5, 7 and 8, 9 and 10, the output parameters of the connected barriers (up to 4) or hazardous location apparatus must meet the following requirements:
  - $V_{oc} \leq$  The lowest  $V_{max}$  of the CSA / FM Approved apparatus in the circuit
  - $I_{sc} \leq$  The lowest  $I_{max}$  of the CSA / FM Approved apparatus in the circuit
  - $P_{max} \leq$  The lowest  $P_{max}$  of the CSA / FM Approved apparatus in the circuit
  - $C_a \geq$  The sum of the cable capacitance and the internal capacitance  $C_i$  of each CSA / FM Approved apparatus installed in the circuit
  - $L_a \geq$  The sum of the cable inductance and the internal inductance  $L_i$  of each CSA / FM Approved apparatus installed in the circuit
- ◆ For the circuits connected to terminals 1 and 2, 4 and 6, 7 and 8, 11 and 12, the input parameters of the connected hazardous location apparatus must meet the following requirements:
  - $V_{max} \geq$  The  $V_{oc}$  of the of the circuit
  - $I_{max} \geq$  The  $I_{sc}$  of the circuit
  - $P_{max} \geq$  The  $P_{max}$  of the circuit
  - $C_i \leq$  The difference between the  $C_a$  of the circuit and the sum of the cable capacitance and the internal capacitance  $C_i$  of all other CSA / FM Approved apparatus installed in the circuit
  - $L_i \leq$  The difference between the  $L_a$  of the circuit and the sum of the cable inductance and the internal inductance  $L_i$  of all other CSA / FM Approved apparatus installed in the circuit
- ◆ Hazardous Location Apparatus – switches, thermocouples or non-inductive resistance devices, or CSA / FM – Certified Apparatus – should be connected in accordance with the manufacturer's installation instructions.
- ◆ The cable parameters are determined by the parameters of the system into which the F0-Series General Purpose Indicators is connected.
- ◆ Only certified Intrinsically Safe Fluidwell battery type FW-LiBat-0xx may be used and replaced in hazardous area.

**The entity parameters for F0-Series General Purpose Indicators, model F0xx-A-PL-XI, are as follows:**

Terminals 1 and 2 – Input parameters:	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 93\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 0.75\text{ W}$	
Terminal 3 – Internally not connected		
Terminal 4 and 5 – Input parameters – Type -PD/-PX	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 200\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 1.2\text{ W}$	
Terminal 4 and 6 – Output parameters – Type -PD	$V_{oc}$ , $I_{sc}$ , $P_{max}$ , $C_a$ and $L_a$ are equal to those of the circuitry connected between terminals 4 and 5.	
Terminal 7 and 8 – Input parameters – Type -OT	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 200\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 1.2\text{ W}$	
Terminal 9 and 10 – Input parameters – Type -ZB	$V_{max} = 30\text{ V}$	$C_i = 0\text{ nF}$
	$I_{max} = 200\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 0.75\text{ W}$	
Terminal 11 and 12 – Input parameters – Type -AH	$V_{max} = 30\text{ V}$	$C_i = 6.1\text{ nF}$
	$I_{max} = 100\text{ mA}$	$L_i = 0\text{ mH}$
	$P_{max} = 0.75\text{ W}$	





## 5.2.4 INSTALLATIONS BASED ON ATEX OR IECEx CERTIFICATE



### Installation instructions

- For installation under **ATEX directive**: this Intrinsically Safe device must be installed in accordance with ATEX directive 2014/34/EU and product certificate KEMA 03ATEX1168 X.
- For installation under **IECEx scheme**: this Intrinsically Safe device must be installed in accordance with product certificate IECEx DEK 08.0006X.

### Covered Ex markings

-  II 1 G Ex ia IIC T4 Ga
-  II 1 D Ex ia IIIC T<sub>200</sub> 100°C Da

### Safety instructions

- When two or more active Intrinsically safe circuits are connected to the indicator, in order to prevent voltage and/or current addition, applicable to the external circuits, precautions must be taken to separate the Intrinsically safe circuits in accordance with EN 60079-11.
- For electrical data, consult Annex 1 for this F0-Series model on the following page.
- Substitution of components may impair intrinsic safety.  
Exchange of Intrinsically safe battery FWLiBAT-0xx with certificate number KEMA 03ATEX1071 U or IECEx KEM 08.0005U is allowed in Hazardous Area.  
Read paragraph 6.3 for battery replacement instructions.

### Specific conditions of use

- When the enclosure of the indicator is made of aluminum alloy, when used in a potentially explosive atmosphere requiring apparatus of equipment category 1 G / equipment protection level Ga, the indicator shall be installed so, that even in the event of rare incidents, an ignition source due to impact or friction sparks between the enclosure and iron/steel is excluded.
- For EPL Da the ambient temperature Ta shall not exceed 50 °C.

## 5.2.5 ELECTRICAL DATA – ANNEX 1

## Annex 1 (model specific)

to product certificates KEMA 03ATEX1168 X, IECEx DEK 08.0006X, DEKRA 21UKEX0202 X.

	Model F0..-A-XI	Model F0..-A-PL-XI
<b>Internal supply</b> Type -PC (connector)	for use with the certified replaceable battery type FW-LiBAT-... or to another certified non rechargeable battery in type of protection intrinsic safety Ex ia IIC/IIIC, with the following maximum values:  <div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 4 \text{ V} \\ I_i &amp; = &amp; 50 \text{ mA} \\ P_i &amp; = &amp; 200 \text{ mW} \end{array}</math></div><div><math display="block">\begin{array}{lcl} L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 0 \text{ }\mu\text{F} \end{array}</math></div></div>	
<b>Analog input circuit</b> (terminals 1 and 2)	Analog input circuit	Loop powered analog input circuit
	in type of protection intrinsic safety Ex ia IIC/IIIC, only for connection to a certified intrinsically safe circuit, with following maximum values:  <div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 30 \text{ V} \\ I_i &amp; = &amp; 150 \text{ mA} \\ P_i &amp; = &amp; 0.92 \text{ W} \\ L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 0 \text{ nF} \end{array}</math></div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 30 \text{ V} \\ I_i &amp; = &amp; 93 \text{ mA} \\ P_i &amp; = &amp; 0.92 \text{ W} \\ L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 0 \text{ nF} \end{array}</math></div></div>	
<b>Reference output circuit</b> (terminals 3 and 1 or 2)	in type of protection intrinsic safety Ex ia IIC/IIIC, with the following maximum values:  Not applicable	
<b>External supply input circuit</b> Type -PD, -PX (terminals 4 and 5)	in type of protection intrinsic safety Ex ia IIC/IIIC, only for connection to a certified intrinsically safe circuit, with following maximum values:  <div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 30 \text{ V} \\ I_i &amp; = &amp; 200 \text{ mA} \\ P_i &amp; = &amp; 1.2 \text{ W} \end{array}</math></div><div><math display="block">\begin{array}{lcl} L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 0 \text{ nF} \end{array}</math></div></div>	
<b>External supply output circuit</b> Type -PD (terminals 6 and 1, 2, 7 or 8)	in type of protection intrinsic safety Ex ia IIC/IIIC, with the following maximum values:  The maximum output parameters are equal to the parameters of the external supply input circuit (terminals 4 and 5)	
<b>Pulse output circuit</b> Type -OT (terminals 7 and 8)	in type of protection intrinsic safety Ex ia IIC/IIIC, only for connection to a certified intrinsically safe circuit, with following maximum values:  <div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 30 \text{ V} \\ I_i &amp; = &amp; 200 \text{ mA} \\ P_i &amp; = &amp; 1.2 \text{ W} \end{array}</math></div><div><math display="block">\begin{array}{lcl} L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 0 \text{ nF} \end{array}</math></div></div>	
<b>Backlight supply input circuit</b> Type -ZB (terminals 9 and 10)	in type of protection intrinsic safety Ex ia IIC/IIIC, only for connection to a certified intrinsically safe circuit, with following maximum values:  <div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 30 \text{ V} \\ I_i &amp; = &amp; 200 \text{ mA} \\ P_i &amp; = &amp; 0.75 \text{ W} \end{array}</math></div><div><math display="block">\begin{array}{lcl} L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 0 \text{ nF} \end{array}</math></div></div>	
<b>Analog output (with HART)</b> Type -AH (terminals 11 and 12)	in type of protection intrinsic safety Ex ia IIC/IIIC, only for connection to a certified intrinsically safe circuit, with following maximum values:  <div><div><math display="block">\begin{array}{lcl} U_i &amp; = &amp; 30 \text{ V} \\ I_i &amp; = &amp; 100 \text{ mA} \\ P_i &amp; = &amp; 0.75 \text{ W} \end{array}</math></div><div><math display="block">\begin{array}{lcl} L_i &amp; = &amp; 0 \text{ mH} \\ C_i &amp; = &amp; 6.1 \text{ nF} \end{array}</math></div></div>	
From the safety point of view the circuits shall be considered to be connected to earth.		

### 5.3 TERMINAL CONNECTORS INTRINSICALLY SAFE APPLICATIONS

#### Terminal connectors F050-A-(PX / PC / PD / PL)-XI-(ZB):




Fig. 21: Overview terminal connectors Type XI - Intrinsically Safe applications

#### 5.3.1 POWER SUPPLY WIRING

The F050-A can be powered from an external power supply. An internal power supply is also available in the form of a lithium battery. When both external and internal power supplies are available, the internal power supply is interrupted and will act as a backup supply. Note that the optional backlight only works with an external power supply.

The following types of power supply are available for hazardous area:


- **Type PX:**  
as standard, all intrinsically safe products are supplied with terminal 4 and 5 to power the product externally.
- **Type PC:**  
offers - additional to type PX - an internal Intrinsically Safe lithium battery. This ATEX certified battery (FW-LiBAT-xxx) may be changed in hazardous area.
- **Type PD:**  
offers a sensor supply on terminal 6 with the same voltage as connected to terminal 5 (internally linked).
- **Type PL:**  
the unit will be powered from the 4-20mA input signal. Terminal 4-6 are not available.

#### 5.3.2 TERMINAL 6 - TYPE PD: SENSOR SUPPLY

Type PD offers a supply for the sensor. Terminal 6 is directly connected to terminal 5, so the offered voltage is the same as connected to terminal 5.

## 5.4 CONFIGURATION EXAMPLES INTRINSICALLY SAFE APPLICATIONS

### 5.4.1 F050-A-PX-XI-ZB - Ex ia IIC/IIIC



**Fig. 22: F050-A-PX-XI-ZB - Ex ia IIC/IIIC - Intrinsically Safe application.**


\*

Sensor supply voltage from unit not available in this example.

Please note: Type PX may be used in combination with the battery (Type PC).

PX will power the F050-A, the battery will be disabled automatically until the power is disconnected.

### 5.4.2 F050-A-PD-XI-ZB - Ex ia IIC/IIIC



**Fig. 23: F050-A-PD-XI-ZB - Ex ia IIC/IIIC - Intrinsically Safe application.**


\*

Sensor supply voltage: terminal 6, same as input voltage terminal 5.

Please note: Type PD may be used in combination with the battery (Type PC).

PD will power the F050-A, the battery will be disabled automatically until the power is disconnected.

### 5.4.3 F050-A-PL-XI-ZB - Ex ia IIC/IIIC



**Fig. 24: F050-A-PL-XI-ZB - Ex ia IIC/IIIC - Intrinsically Safe application.**

\*

Sensor supply voltage not available in this example.

Please note: Type PL may be used in combination with the battery (Type PC).

PL will power the F050-A, the battery will be disabled automatically until the power is disconnected.

## 6 MAINTENANCE

### 6.1 GENERAL DIRECTIONS



Caution !

- Mounting, electrical installation, start-up and maintenance of the instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must read and understand this Operating Manual before carrying out its instructions.
- The F050-A may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed.
- Ensure that the measuring system is correctly wired up according to the wiring diagrams. The housing may only be opened by trained personnel.
- Take careful notice of the "Safety rules, instructions and precautionary measures" in the front of this manual.

The F050-A does not require special maintenance unless it is used in low-temperature applications or surroundings with high humidity (above 90% annual mean). It is the users responsibility to take all precautions to dehumidify the internal atmosphere of the F050-A in such a way that no condensation will occur, for example by placing dry silica-gel sachet in the casing just before closing it. Furthermore, it is required to replace or dry the silica gel periodically as advised by the silica gel supplier.

#### Battery life-time:



Note !

*It is strongly advised to use only necessary functions.*

It is influenced by several issues :

- Display update: fast display update uses significantly more power.
- Pulse output.
- Low temperatures; the available power will be less due to battery chemistry.

#### Check periodically:

- The condition of the casing, cable glands and front panel.
- The input/output wiring for reliability and aging symptoms.
- The process accuracy. As a result of wear and tear, re-calibration of the flowmeter might be necessary. Do not forget to re-enter any subsequent Span alterations.
- The indication for low-battery.
- Clean the casing with soapy-water. Do not use any aggressive solvents as these might damage the coating.

### 6.2 INSTRUCTIONS FOR REPAIR

This product cannot be repaired by the user and must be replaced with an equivalent certified product. Repairs are only allowed to be carried out by the manufacturer or his authorized agent.



**Substitution of components may impair intrinsic safety.**

#### Repair policy

If you have any problem with your product and you wish to have it repaired, please follow the procedure below:

- Obtain a Return Material Authorization (RMA) from your supplier or distributor. Together with the RMA, you need to complete a repair form to submit detailed information about the problem.
- Send the product, within 30 days, to the address provided with the RMA. The physical return of your repair can only take place after the authorization of your repair application, as confirmed by the RMA number.

If the product is within the warranty period and the reported problem falls under the warranty conditions, the product will be repaired or exchanged and returned within three weeks. Otherwise, you will receive a repair estimate.

## 6.3 BATTERY REPLACEMENT

### 6.3.1 SAFETY INSTRUCTIONS



- Handle the battery with the utmost care to prevent a short circuit and damage. A mistreated battery can become unsafe. Unsafe batteries can cause (serious) injury to persons. **Do not recharge, crush, disassemble, incinerate, heat above its rated temperature or expose the contents to water.**
- Mounting, electrical installation, start-up and maintenance of this device may only be carried out by trained persons authorized by the operator of the facility. Persons must read and understand this manual before carrying out its instructions.



#### Intrinsically safe applications – Type PC

- Only batteries of type FW-LiBAT-021 that hold the Ex marking as shown below are suitable replacements and certified for use in hazardous areas.
- Before replacing the battery in hazardous area, verify that the new battery is undamaged, in good condition and suitable for use in the unit.  
(Type: FW-LiBAT-021 - re-ordering nr. SPC02)
- Never use safe areas batteries in hazardous area. **DO NOT EXCHANGE.**  
Using the wrong type of battery can pose a **SERIOUS RISK.**




Fig. 25: Marking Type PC battery: Intrinsically Safe FW-LiBAT-021 (SPC02)



#### Safe area applications – Type PB

- Before replacing the battery, verify that the new battery is undamaged, in good condition and suitable for use in the unit.  
(Type: StdLiBAT021 - re-ordering nr. SPB02)




Fig. 26: Marking Type PB battery: Safe area StdLiBAT021 (SPB02)

### 6.3.2 REPLACE THE BATTERY



Before starting the battery replacement procedure, make sure that the marking on the new battery corresponds with the type of installation, as shown in paragraph 6.3.1.



When used in Intrinsically safe applications – Type PC:

The VELCRO strap that holds the battery is antistatic: **DO NOT REPLACE**.  
When lost or broken, temporarily use a tie-wrap to hold the battery.

#### Remove the old battery as follows:

1. Open the enclosure as indicated in section 4.3 and locate the battery on the inside cover.
2. Carefully disconnect the battery connector (1) from the unit.
3. Open the Velcro strap (2) without pulling it out and remove the battery (3) from its retainer (4).
4. Store the old battery in a small plastic bag (e.g. the bag the new battery came in) or install an insulation tape over the battery connector to prevent a short circuit.




Fig. 27: Battery replacement procedure

#### Install the new battery as follows:

1. Make sure the new battery is undamaged, in good condition and suitable for use in the unit.  
Check that the markings on the battery correspond with the type of installation, as shown above.
2. Install the battery (3) into the retainer (4) making sure the wire (1) comes out at the correct side.
3. Close the Velcro strap (2) tightly around the battery (3) to secure it in place.
4. Carefully connect the battery connector (1) to the unit.
5. Check that the battery is installed properly by checking that the screen has come on.
6. Close the enclosure as indicated in section 4.3.
7. If required, initialize the date and time on the unit.

### 6.3.3 DISPOSAL OF BATTERIES

Dispose of batteries in accordance with the (inter)national, the manufacturer's and the plant owner's standards and regulations.





- Batteries pose an environmental hazard.
- Do not dispose of as general waste or incinerate.
- Return used batteries to a recycling point.



## Appendix A. TECHNICAL SPECIFICATION

### General

<b>Display</b>	
Type	High intensity reflective numeric and alphanumeric LCD, UV-resistant.
Dimensions	90 x 40mm (3.5" x 1.6")
Digits	5 ½ 26mm (1") and eleven 8mm (0.31"). Various symbols and measuring units.
Piegraph	10 segment range indication in relation to its measuring range 0-100%
Refresh rate	User definable: 8 times/sec - 15 secs.
Type ZB (option)	Configurable LED-backlight. Intensity adjustable from the keyboard.
<b>Enclosures</b>	
General	Die-cast aluminum, Stainless Steel 316L or GRP (Glass Reinforced Plastic) wall / field mount enclosure with Polycarbonate window, silicone and EPDM gaskets. UV stabilized and flame retardant material.
Control Keys	Three industrial micro-switch keys. UV-resistant silicone keypad.
Painting	Aluminum enclosure only: UV-resistant 2-component industrial painting.
Panel mount enclosures	
Dimensions	130 x 120 x 60mm (5.10" x 4.72" x 2.38") – WxHxD
Panel cut-out	115 x 98mm (4.53" x 3.86") – WxH
Protruding at front	31mm (1.22")
Classification	IP65 / TYPE 4X
Type HC	Plastic / GRP panel-mount enclosure. Weight 450gr.
Type HB / HSB	Aluminum / Stainless Steel panel-mount enclosure. Weight 600gr.
Field/wall-mount enclosures	
Dimensions	130 x 120 x 75mm (5.10" x 4.72" x 2.95") – WxHxD
with extended back	130 x 120 x 90mm (5.10" x 4.72" x 3.54") – WxHxD
Classification	IP67 / TYPE 4X
Aluminum / SS enclosures	(types HS_ are stainless steel versions, HB_ are extended aluminum back versions)
Type HA	Drilling: 2x PG9 – 1x M20.
Type HB / HSB	Panel mount front cover only
Type HL	Drilling: 2x ½"NPT.
Type HM / HBM / HSM	Drilling: 2x M16 – 1x M20.
Type HN	Drilling: 1x M20.
Type HO / HBO / HSO	Drilling: 2x M20.
Type HP	Drilling: 6x M12.
Type HT	Drilling: 1x ½"NPT.
Type HU / HBU / HSU	Drilling: 3x ½"NPT.
Type HV	Drilling: 4x M20
Type HZ	No drilling.
GRP enclosures	
Type HC	Panel mount front cover only
Type HD	No drilling.
Type HE	Drilling: 2x 16mm (0.63") – 1x 20mm (0.78").
Type HF	Drilling: 1x 22mm (0.87").
Type HG	Drilling: 2x 20mm (0.78").
Type HH	Drilling: 6x 12mm (0.47").
Type HJ	Drilling: 3x 22mm (0.87").
Type HK	Flat bottom - no drilling.
<b>Operating temperature</b>	
Safe area	-40°C to +80°C (-40°F to +178°F).
Intrinsically Safe	-40°C to +70°C (-40°F to +158°F). For EPL Da: -40°C to +50°C (-40°F to +122°F)

Power requirements		
Type PB	Standard Lithium battery - life-time depends upon settings - up to 5 years. <b>SAFE AREA ONLY</b>	
Type PC	<b>Intrinsically Safe</b> lithium battery - life-time depends upon settings - up to 5 years.	
Type PD	16-30 V DC. Power consumption max. 1 Watt.	
Type PF	24V AC/DC $\pm 10\%$ . Power consumption max. 15 Watt.	
Type PL	Input loop powered from 4-20mA signal. Voltage drop max. 2.6V DC.	
Type PM	115-230V AC $\pm 10\%$ . Power consumption max. 15 Watt.	
Type PX	8-30 V DC (also available with PB / PC). Power consumption max. 0.3 Watt.	
Type ZB	20-30V DC. Power consumption max. 1 Watt. Note: with type PF / PM: internally powered.	
Note for Type PF and PM	The total consumption of the sensor, transistor output type OA and backlight type ZB may not exceed 400mA@24V DC.	
Note for I.S. applications	For <b>Intrinsically safe</b> applications, consult the safety values in the certificate.	
Sensor excitation		
Type PD	Sensor supply directly branched from unit supply.	
Type PF / PM	Sensor supply 8.2V, 12V and 24V DC - max. 400mA@24V DC	
Terminal connections		
Type:	Removable plug-in terminal strip. Wire max. 1.5mm <sup>2</sup> and 2.5mm <sup>2</sup>	
Data protection		
Type	EEPROM backup of all settings. Data retention at least 10 years.	
Password	Configuration settings can be password protected.	
Hazardous area (option)		
Intrinsically safe Type XI	<b>ATEX approval: KEMA 05ATEX1168 X</b>  II 1 G Ex ia IIC T4 Ga II 1 D Ex ia IIIC T <sub>200</sub> 100°C Da	<b>CSA approval: CSA.08.2059461</b> IS Class I/II/III, Division 1, Groups A to G T4 Class I, Zone 0, AEx ia IIC T4 Ga
	<b>IECEx approval: IECEx KEM 08.0006X</b> Ex ia IIC T4 Ga Ex ia IIIC T <sub>200</sub> 100°C Da	<b>FM approval: FM16US0177X</b> project ID: 3033306 IS Class I/II/III, Division 1, Groups A to G T4 Class I, Zone 0, AEx ia IIC T4 Ga
Explosion proof Type XF	<b>ATEX approval:</b>  II 2 G Ex db IIB+H2 T5 Gb II 2 D Ex tb IIIC T80°C Db	<b>IECEx approval:</b> Ex db IIB+H2 T5 Gb Ex tb IIIC T80°C Db
Weight Dimensions	Appr. 15 kg. 350 x 250 x 200mm (13.7" x 9.9" x 7.9") WxHxD.	
Directives & Standards		
EMC	EN 61326-1	FCC 47 CFR part 15
Low voltage	EN/IEC 61010-1	CSA C22.2 No. 61010-1      UL61010-1
ATEX	EN IEC 60079-0	EN 60079-11
IECEx	IEC 60079-0	IEC 60079-11
CSA c-us	CAN/CSA-C22.2 NO. 157 CAN/CSA-C22.2 NO. 142 CAN/CSA-C22.2 NO. 60079-0 CAN/CSA-C22.2 NO. 60079-11	ANSI/UL 913 UL 508 ANSI/ISA-60079-0 ANSI/ISA-60079-11
FM	FM Class 3600 FM Class 3610 FM Class 3810	ANSI/UL 60079-0 ANSI/UL 60079-11
RoHS	EN 50581	IEC 63000
IP & NEMA	EN 60529	ANSI/IEC 60529      NEMA 250
Note: See the applicable Declaration of Conformity or product certificate for specific revisions and publication dates.		

**Input**

<b>SENSOR</b>	
Type A	(0)4-20 mA, with signal calibration feature
Accuracy	Resolution: 16 bit. Error < 0.01mA / $\pm 0.05\%$ FS. Low level cut-off programmable.
Span	0.00001 - 199,999 with variable decimal position.
Offset	-99.999 to +199.999 units
Update time	Four times a second.
Voltage drop	2.6 Volt.
Load impedance	3kOhm
Relationship	Linear.

**Operational**

<b>Operator functions</b>	
Displayed functions	<ul style="list-style-type: none"> <li>• pressure</li> <li>• measuring unit</li> <li>• piegraph 0-100%.</li> </ul>

<b>Pressure</b>	
Digits	5 1/2 digits.
Unit	mBar - Bar - PSI - mPA - PA - no unit.
Decimals	0 - 5.

## Appendix B. PROBLEM SOLVING

In this appendix, several problems are included that can occur when the F050-A is going to be installed or while it is in operation.

### **Pressure displays "0 / zero" while a signal is available:**

Check:

- SETUP 1.3: is the span correct?
- SETUP 1.4: is the offset value correct?
- SETUP 4.3/4.4: is the sensor input signal correctly calibrated?

### **Range error**

- Range error (LO RANGE or HI RANGE): the input value is at least 5% above or below the calibrated measurement range SETUP 4.3, 4.4. Do recalibrate the input if desired.

### **The pass code is unknown:**

If the pass code is not 1234, there is only one possibility left: call your supplier.

### **ALARM**

When the alarm flag starts to blink an internal alarm condition has occurred. Press the "select button" several times to display the 4-digit error code. The codes are:

- 0001:  
irrecoverable display-data error: data on the display might be corrupted.
- 0002:  
irrecoverable data-storage error: the programming cycle might have gone wrong: check programmed values.
- 0003:  
error 1 and error 2 occurred simultaneously

The alarm condition will almost certainly be handled internally and if all mentioned values still appear correct, no intervention by the operator is needed. If the alarm occurs more often or stays active for a longer time, please contact your supplier.

## INDEX OF THIS MANUAL

actual settings	48	main-function	9
backlight	27	maintenance	38
bargraph	13	operational	7, 9, 16, 29, 38
battery low	8	operator level	7
Configuration	9	pass code	44
contents	4	<b>Piegraph</b>	8, 13
dimensions metal enclosures	20, 21	power supply	27
<b>display pressure</b>	7	pressure	
display update time	14	decimals	13
functional description	6	measuring unit	13
high current	44	span	13
input signal	26	<b>range error</b>	8, 44
intrinsic safety	29	sensor supply voltage	25
Intrinsic safety	30, 38, 40	SETUP-level	9
keys	7	signal input	26
low current	44	terminal connectors	26, 27

## LIST OF FIGURES

Fig. 1: Typical application for the F050-A.	6
Fig. 2: Control panel.	7
Fig. 3: Example of display information during process.	7
Fig. 4: Example of low-battery alarm.	8
Fig. 5: SETUP matrix structure	9
Fig. 6: Identification – Example of F0-Series identification label (safe area)	17
Fig. 7: Identification – Example of F0-Series installation label (safe area - Type PB, PX or PD)	17
Fig. 8: Identification – Example of F0-Series installation label (safe area - Type PM or PF))	18
Fig. 9: Dimensions – Aluminum and stainless steel enclosures	20
Fig. 10: Dimensions – Non-metallic enclosures	21
Fig. 11: Installation – Mounting configurations	22
Fig. 12: Protective Earth (PE) connections on metal enclosure	24
Fig. 13: Switch position voltage selection (type PF and PM).	25
Fig. 14: Overview of terminal connectors F050-A – type PB / PD / PL / PX	26
Fig. 15: Terminal connections - Analog signal input.	26
Fig. 16: Terminal connections - Backlight (ZB).	27
Fig. 17: Overview of terminal connectors F050-A – type PF / PM	27
Fig. 18: Terminal connections - Analog signal input.	28
Fig. 19: Identification – Example of F0-Series identification label (intrinsic safety)	29
Fig. 20: Identification – Example of F0-Series installation label (intrinsic safety)	29
Fig. 21: Overview terminal connectors Type XI - Intrinsically Safe applications	35
Fig. 22: F050-A-PX-XI-ZB - Ex ia IIC/IIIC - Intrinsically Safe application.	36
Fig. 23: F050-A-PD-XI-ZB - Ex ia IIC/IIIC - Intrinsically Safe application.	36
Fig. 24: F050-A-PL-XI-ZB - Ex ia IIC/IIIC - Intrinsically Safe application.	37
Fig. 25: Marking Type PC battery: Intrinsically Safe FW-LiBAT-021 (SPC02)	39
Fig. 26: Marking Type PB battery: Safe area StdLiBAT021 (SPB02)	39
Fig. 27: Battery replacement procedure	40

LIST OF CONFIGURATION SETTINGS			
SETTING	DEFAULT	DATE:	DATE:
<b>1 - PRESSURE</b>		Enter your settings here	
1.1 unit	Bar		
1.2 decimals	00000		
1.3 span	00001		
1.4 offset	00000		
<b>2 - DISPLAY</b>			
2.1 bargraph	on		
2.2 backlight	off		
2.3 brightness	5		
<b>3 - POWER MANAGEMENT</b>			
3.1 LCD-new	1 sec.		
3.2 mode	operational		
<b>4 - SENSOR</b>			
4.1 filter	01 (off)		
4.2 cut-off	00.0%		
4.3 calibration low (0)4mA	factory		
4.4 calibration high 20mA	factory		
<b>5 - OTHERS</b>			
5.1 model	F050-A	F050-A	F050-A
5.2 software version	03.____.____	03.____.____	03.____.____
5.3 serial number	____-____-____	____-____-____	____-____-____
5.4 pass code	0000		
5.5 tagnumber	0000000		